


17", 19" Auto scan Color Monitor

Service
Service
Service



17A580BQ/74C
19A580BQ/74C



MANUAL 6604

PCEC Model: 17A580 BQ11
19A580 BQ11

Chassis: CM5800

File: 1997: 6604

DDC/Audio/Power saving/Tilt correction

Service Manual

Horizontal frequencies
30 - 95 kHz

TABLE OF CONTENTS

Description	Page	Description	Page
PART-I : Technical data		U-CTRL (B3) Schematic Diagram-----	22
Important Safety Notice -----	2	Power Supply (C) Schematic Diagram-----	23
Hex Data of DDC1/2B-----	3~6	Main Panel (B1, B2, B3, C & D) C.B.A.-----	24
Warning and Notes -----	7	Audio (D) and USB (E) Schematic Diagram-----	25
Electrical Adjustments -----	8,9	Earphone (F), Rotary and Power Switch (G)-----	26
USB Connections-----	10	Rotary Panel (G) & USB Panel C.B.A. (E)-----	27
Quick Reference for OSD Adjustment-----	11~14	Repair Tips and Exploded View -----	28
Mechanical Adjustments and Wiring diagram ----	15	Spare parts list-----	29~33
Block Diagram -----	16	Quick Reference for 17" & 19" Monitors -----	34,35
Video (A), Power Switch (G), Earphone (F) & Terminal Panel (A1) C.B.A.-----	17	CM5800 BRIEF -----	36~39
Terminal Panel (A1) Schematic Diagram -----	18	PART-II : Service Information 4822 727 21995 (for using the Service DDC Kit)	
Video Panel (A2) Schematic Diagram -----	19	PART-III: The control software for monitors through USB (Installation Manual)	
Main Panel (B1) Schematic Diagram-----	20	PART-IV: Directions For Use	
Main Panel (B2) Schematic Diagram-----	21		

REFER TO BACK COVER FOR IMPORTANT SAFETY GUIDELINES

SAFETY NOTICE

ANY PERSON ATTEMPTING TO SERVICE THIS CHASSIS MUST FAMILIARIZE HIMSELF WITH THE CHASSIS AND BE AWARE OF THE NECESSARY SAFETY PRECAUTIONS TO BE USED WHEN SERVICING ELECTRONIC EQUIPMENT CONTAINING HIGH VOLTAGES.

CAUTION: USE A SEPARATE ISOLATION TRANSFORMER FOR THIS UNIT WHEN SERVICING.



PHILIPS

IMPORTANT SAFETY NOTICE

Proper service and repair is important to the safe, reliable operation of all Philips Consumer Electronics Company** Equipment. The service procedures recommended by Philips and described in this service manual are effective methods of performing service operations. Some of these service operations require the use of tools specially designed for the purpose. The special tools should be used when and as recommended.

It is important to note that this manual contains various CAUTIONS and NOTICES which should be carefully read in order to minimize the risk of personal injury to service personnel. The possibility exists that improper service methods may damage the equipment. It also is important to understand that these CAUTIONS and NOTICES ARE NOT EXHAUSTIVE. Philips could not possibly know, evaluate and advise the service trade of all conceivable ways in which service might be done or of the possible hazardous consequences of each way. Consequently, Philips has not undertaken any such broad evaluation. Accordingly, a servicer who uses a service procedure or tool which is not recommended by Philips must first satisfy himself thoroughly that neither his safety nor the safe operation of the equipment will be jeopardized by the service method selected.

* * Hereafter throughout this manual, Philips Consumer Electronics Company will be referred to as Philips.

WARNING

Critical components having special safety characteristics are identified with a Δ by the Ref. No. in the parts list and enclosed within a broken line* (where several critical components are grouped in one area) along with the safety symbol Δ on the schematics or exploded views.

Use of substitute replacement parts which do not have the same specified safety characteristics may create shock, fire, or other hazards.

Under no circumstances should the original design be modified or altered without written permission from Philips. Philips assumes no liability, express or implied, arising out of any unauthorized modification of design. Servicer assumes all liability.

* Broken Line 

FOR PRODUCTS CONTAINING LASER :

DANGER- Invisible laser radiation when open. AVOID DIRECT EXPOSURE TO BEAM.

CAUTION- Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

CAUTION- The use of optical instruments with this product will increase eye hazard.

TO ENSURE THE CONTINUED RELIABILITY OF THIS PRODUCT, USE ONLY ORIGINAL MANUFACTURER'S REPLACEMENT PARTS, WHICH ARE LISTED WITH THEIR PART NUMBERS IN THE PARTS LIST SECTION OF THIS SERVICE MANUAL.

ddc_v17.chk	
Vendor/Product Identification	
ID Manufacturer Name	: PHL
ID Product Code	: 1107
ID Serial Number	: 12345678
Week of Manufacture	: 38
Year of Manufacture	: 1997
EDID Version, Revision	
Version	: 1
Revision	: 1
Basic Display Parameters/Features	
Video Input Definition	: Analog Video Input 0.700V/0.300V (1.00Vpp) without Blank-to-Black Setup Separate Sync Composite Sync Sync on Green no Serration required
Maximum H Image Size	: 30 cm
Maximum V Image Size	: 23 cm
Display Transfer Characteristic: 2.850 (gamma)	
Feature Support (DPMS)	: Standby Suspend Active Off RGB color display
Color Characteristics	
Red X coordinate	: 0.625
Red Y coordinate	: 0.340
Green X coordinate	: 0.285
Green Y coordinate	: 0.605
Blue X coordinate	: 0.150
Blue Y coordinate	: 0.065
White X coordinate	: 0.283
White Y coordinate	: 0.298
Established Timings	
Established Timings I	: 640 x 480 @60Hz (VGA,IBM) 640 x 480 @75Hz (VESA)
Established timings II	: 800 x 600 @75Hz (VESA) 1024 x 768 @75Hz (VESA) 1280 x 1024 @75Hz (VESA)
Manufacturer's timings	: 1152 x 870 @75Hz (MacII,Apple)
Standard Timing Identification #1	
Horizontal active pixels	: 640
Aspect Ratio	: 4:3
Refresh Rate	: 70
Standard Timing Identification #2	
Horizontal active pixels	: 800
Aspect Ratio	: 4:3
Refresh Rate	: 85
Standard Timing Identification #3	
Horizontal active pixels	: 1024
Aspect Ratio	: 4:3
Refresh Rate	: 85
Standard Timing Identification #4	
Horizontal active pixels	: 1280

Aspect Ratio	: 5:4
Refresh Rate	: 85
Standard Timing Identification #5	
Horizontal active pixels	: 1600
Aspect Ratio	: 4:3
Refresh Rate	: 75
Detailed Timing #1	
Pixel Clock (MHz)	: 108.000
H Active (pixels)	: 1152
H Blanking (pixels)	: 352
V Active (lines)	: 900
V Blanking (lines)	: 43
H Sync Offset (F Porch) (pixels): 16	
H Sync Pulse Width (pixels) : 64	
V Sync Offset (F Porch) (lines): 2	
V Sync Pulse Width (lines) : 8	
H Image Size (mm) : 300	
V Image Size (mm) : 225	
H Border (pixels) : 0	
V Border (lines) : 0	
Flags	: Non-interlaced Normal Display, No stereo Digital Separate Sync Positive V Sync Positive H Sync
Monitor Descriptor #2	
Serial Number	: CM58C12345678
Monitor Descriptor #3	
Monitor Name	: TYPHOON 17A
Monitor Descriptor #4	
Min. Vt rate Hz	: 50
Max. Vt rate Hz	: 160
Min. Horiz. rate kHz	: 30
Max. Horiz. rate kHz	: 95
Max. Supported Pixel not specified	
Extension Flag	: 0
Check sum	: 5e(hex)

Hex Data of DDC1/2B (17A580BQ/74C)

```

0: 0    1: ff    2: ff    3: ff    4: ff    5: ff    6: ff    7: 0
8: 41   9: c    10: 7   11: 11  12: 4e  13: 61  14: bc  15: 0
16: 26  17: 7   18: 1   19: 1   20: e   21: 1e  22: 17  23: b9
24: e8  25: 0   26: b9  27: a0  28: 57  29: 49  30: 9b  31: 26
32: 10  33: 48  34: 4c  35: 24  36: 43  37: 80  38: 31  39: 4a
40: 45  41: 59  42: 61  43: 59  44: 81  45: 99  46: a9  47: 4f
48: 1    49: 1   50: 1   51: 1   52: 1   53: 1   54: 30  55: 2a
56: 80  57: 60  58: 41  59: 84  60: 2b  61: 30  62: 10  63: 40
64: 28  65: 0   66: 2c  67: e1  68: 10  69: 0   70: 0   71: 1e
72: 0    73: 0   74: 0   75: ff  76: 0   77: 43  78: 4d  79: 35
80: 38  81: 43  82: 31  83: 32  84: 33  85: 34  86: 35  87: 36
88: 37  89: 38  90: 0   91: 0   92: 0   93: fc  94: 0   95: 54
96: 59  97: 50  98: 48  99: 4f  100: 4f  101: 4e  102: 20  103: 31
104: 37  105: 41  106: a   107: 20  108: 0   109: 0   110: 0   111: fd
112: 0   113: 32  114: a0  115: 1e  116: 5f  117: ff  118: 0   119: a
120: 20  121: 20  122: 20  123: 20  124: 20  125: 20  126: 0   127: 5e

```

Hex Data of DDC1/2B (19A580BQ/74C)

Display data channel :DDC1/2B

Vendor/Product Identification

```

ID Manufacturer Name : PHL
ID Product Code      : 1109
ID Serial Number     : 12345678
Week of Manufacture  : 36
Year of Manufacture   : 1997

```

EDID Version, Revision

```

Version : 1
Revision : 1

```

Basic Display Parameters/Features

```

Video Input Definition : Analog Video Input
                        : 0.700V/0.300V (1.00Vpp)
                        : without Blank-to-Black Setup
                        : Separate Sync
                        : Composite Sync
                        : without Sync on Green
                        : no Serration required

```

Maximum H Image Size : 34 cm

Maximum V Image Size : 25 cm

Display Transfer Characteristic (gamma) : 2.760

Feature Support (DPMS)

```

: Standby
: Suspend
: Active Off
: RGB color display

```

Color Characteristics

```

Red X coordinate : 0.625
Red Y coordinate : 0.340
Green X coordinate : 0.285
Green Y coordinate : 0.605
Blue X coordinate : 0.150
Blue Y coordinate : 0.065
White X coordinate : 0.283
White Y coordinate : 0.298

```

Established Timings

```

Established Timings I : 640 x 480 @60Hz (VGA,IBM)
                       : 640 x 480 @75Hz (VESA)

```

Established Timings II

```

: 800 x 600 @75Hz (VESA)
: 1024 x 768 @75Hz (VESA)
: 1280 x 1024 @75Hz (VESA)

```

Manufacturer's Timings

```

: 1152 x 870 @75Hz
: (MacII, Apple)

```

Standard Timing Identification #1

```

Horizontal active pixels : 800
Aspect Ratio             : 4:3
Refresh Rate             : 85

```

Standard Timing Identification #2

```

Horizontal active pixels : 1024
Aspect Ratio             : 4:3
Refresh Rate             : 85

```

Standard Timing Identification #3

```

Horizontal active pixels : 1280
Aspect Ratio             : 5:4
Refresh Rate             : 85

```

Standard Timing Identification #4

```

Horizontal active pixels : 1600
Aspect Ratio             : 4:3
Refresh Rate             : 75

```

Detailed Timing #1

```

Pixel Clock (MHz)       : 202.500
H Active (pixels)       : 1600
H Blanking (pixels)     : 560
V Active (lines)        : 1200
V Blanking (lines)      : 50
H Sync Offset (F Porch) (pixels) : 304
H Sync Pulse Width (pixels) : 192
V Sync Offset (F Porch) (lines) : 46
V Sync Pulse Width (lines) : 3
H Image Size (mm)       : 340
V Image Size (mm)       : 255
H Border (pixels)       : 0
V Border (lines)        : 0
Flags                   : Non-interlaced
                        : Normal Display, No stereo
                        : Digital Separate Sync
                        : Positive V Sync
                        : Positive H Sync

```

Monitor Descriptor #2

Serial Number : 5800C12345678

Monitor Descriptor #3

Monitor Name : TYPHOON 19A

Monitor Descriptor #4

```

Min. Vt rate Hz : 50
Max. Vt rate Hz : 160
Min. Horiz. rate kHz : 30
Min. Horiz. rate kHz : 95
Max. Supported Pixel not specified

```

Extension Flag

: 0

Check sum

: 5e(hex)

For Hitachi CRT



0: 0	1: ff	2: ff	3: ff	4: ff	5: ff	6: ff	7: 0
8: 41	9: c	10: 9	11: 11	12: 4e	13: 61	14: bc	15: 0
16: 24	17: 7	18: 1	19: 1	20: c	21: 22	22: 19	23: b0
24: e8	25: 0	26: b9	27: a0	28: 57	29: 49	30: 9b	31: 26
32: 10	33: 48	34: 4c	35: 24	36: 43	37: 80	38: 45	39: 59
40: 61	41: 59	42: 81	43: 99	44: a9	45: 4f	46: 1	47: 1
48: 1	49: 1	50: 1	51: 1	52: 1	53: 1	54: 1a	55: 4f
56: 40	57: 30	58: 62	59: b0	60: 32	61: 40	62: 30	63: c0
64: e3	65: 48	66: 54	67: ff	68: 10	69: 0	70: 0	71: 1e
72: 0	73: 0	74: 0	75: ff	76: 0	77: 35	78: 38	79: 30
80: 30	81: 43	82: 31	83: 32	84: 33	85: 34	86: 35	87: 36
88: 37	89: 38	90: 0	91: 0	92: 0	93: fc	94: 0	95: 54
96: 59	97: 50	98: 48	99: 4f	100: 4f	101: 4e	102: 20	103: 31
104: 39	105: 41	106: a	107: 20	108: 0	109: 0	110: 0	111: fd
112: 0	113: 32	114: a0	115: 1e	116: 5f	117: ff	118: 0	119: a
120: 20	121: 20	122: 20	123: 20	124: 20	125: 20	126: 0	127: 8e

a: Service DDC Kit

DDC Module (DDC cable), Part number = 4822 320 12004
DDCV2N.EXE software (3.5" disk), Part number = 4822 711 00024

b: Please refer to Service Information 4822 727 21995 for using the Service DDC Kit.

Warnings

1. Safety regulations require that the unit should be returned in its original condition and that components identical to the original components are used. The safety components are indicated by the symbol .
2. In order to prevent damage to ICs and transistors, all high-voltage flash-overs must be avoided. In order to prevent damage to the picture tube, the method shown in Fig. 1 should be used to discharge the picture tube. Use a high-voltage probe and a multimeter (position DC-V). Discharge until the meter reading is 0 V (after approximately 30 seconds).
3. **ESD** .
All ICs and many other semiconductors are sensitive to electrostatic discharges (ESD). Careless handling during repair can drastically shorten their life. Make sure that during repair you are connected by a pulse band with resistance to the same potential as the ground of the unit. Keep components and tools also at this same potential.
4. When repairing a unit, always connect it to the AC Power voltage via an isolating transformer.
5. Be careful when taking measurements in the high-voltage section and on the picture tube panel.
6. It is recommended that safety goggles be worn when replacing the picture tube.
7. When making adjustments, use plastic rather than metal tools. This will prevent any short-circuit or the danger of a circuit becoming unstable.
8. Never replace modules or other components while the unit is switched on.
9. Together with the deflection unit, the picture tube is used as an integrated unit. Adjustment of this unit during repair is not recommended.
10. After repair, the wiring should be fastened in place with the cable clamps.

Notes

1. The direct voltages and waveforms are average voltages. They have been measured using the Service test software and under the following conditions :
- Mode : 1024 * 768 (56.5kHz / 70Hz)
- Signal pattern : grey scale
- Adjust brightness and contrast control for the mechanical mid-position (click position)
2. The picture tube panel has printed spark gaps. Each spark gap is connected between an electrode of the picture tube and the Aquadag coating.
3. The semiconductors indicated in the circuit diagram(s) and in the parts lists are completely interchangeable per position with the semiconductors in the unit, irrespective of the type indication on these semiconductors.




Fig.1

Electrical Adjustments

0. General

When carry-out the electrical settings in many cases a video signal must be applied to the monitor. A computer with :

- ATI GPT-1600 (4822 397 10065), Mach 64 (up to 107kHz)

are used as the video signal source. The signal patterns are selected from the "service test software" package, see user guide 4822 727 21046 (GPT-1600).

0.1 This monitor has 12 factory-preset modes as below.

640 x 400 31.5 kHz/70 Hz	1152 x 870 68.7 kHz/75 Hz
640 x 480 31.5 kHz/60 Hz	1152 x 900 71.8 kHz/76 Hz
640 x 480 37.5 kHz/75 Hz	1280 x 1024 80.0 kHz/75 Hz
800 x 600 46.9 kHz/75 Hz	1280 x 1024 91.1 kHz/85 Hz
800 x 600 53.7 kHz/85 Hz	1600 x 1200 93.7 kHz/75 Hz
1024 x 768 60.0 kHz/75 Hz	
1024 x 768 68.7 kHz/85 Hz	

0.2 With normal VGA card:

If not using the ATI card during repair or alignment, The service engineer also can use this service test software adapting with normal standard VGA adaptor and using standard VGA mode 640 x 480, 31.5 kHz/60 Hz (only) as signal source.

0.3 AC/DC Measurement:

The measurements for AC waveform and DC figure is based on 640 x 480 31.5 kHz/60 Hz resolution mode with test pattern "gray scale".
Power input: 110V AC

1. B+ supply voltage (3194) 185Vdc

- Apply a video signal in the 1024 x 768 with 69 kHz/85Hz mode.
- Select the "cross-hatch" pattern.
- Set the brightness control and the contrast control to the minimum position.
- Pre-set trimming potentiometer 3194(+) and 3644(EHT) in mid-position.
- Set Vg2 (screen) to fully Counter-clockwise (zero beamcurrent).
- Connect a dc voltmeter between the joint of capacitor 2181 and ground (common ground).
- Set the B+ trimming potentiometer 3194 so that the reading on the dc voltmeter is 185 V +/- 0.5 Vdc.

2. High-voltage EHT (3644)

- Apply a video signal in the 1024 x 768 with 69 kHz/85Hz mode.
- Select the "cross-hatch" pattern.
- Set the brightness control and the contrast control to the minimum position.
- Turn off the power.
- Connect a "high-voltage voltmeter" between the high-voltage connection of the picture tube and earth.
- Turn on the power.
- Set the EHT trimming potentiometer 3644 so that the "high-voltage voltmeter" reads 26.0 kV +/- 0.2 kV (for 19").
25.0 kV +/- 0.2 kV (for 17").

- Turn off the power.
- Remove the "high-voltage voltmeter" from the picture tube.
- Turn on the power again.
- Remove the "high-voltage voltmeter" from the picture tube.
- Turn on the power again.

3. Monitor the following auxiliary voltages.

- + 12.0V SOURCE ACROSS C2192 + 12.0V +/- 0.5VDC.
- + 15.0V SOURCE ACROSS C2187 + 15.0V +/- 1.0VDC.
- 15.0V SOURCE ACROSS C2189 - 15.0 V +/- 1.0VDC.
- + 6.3 V SOURCE ACROSS D6195"- 6.3V +/- 0.5VDC.
- +125.0V SOURCE ACROSS C2182 +125.0V +/- 2.0VDC.
- +185.0V SOURCE ACROSS C2181 + 185.0V +/- 1.5VDC.
- + 81.0V SOURCE ACROSS C2185 + 81.0 V +/- 2.0VDC.

4. General conditions for alignment

- 4.1 During all alignments, supply a distortion free AC mains voltage to set via an isolating transformer with low internal impedance.
- 4.2 Align in pre-warmed condition, at least 30 minutes warm-up with nominal picture brightness.
- 4.3 Purity, geometry and subsequent alignments should be carried out in magnetic cage with correct magnetic field.

Northern hemisphere : H=0, V=430 mG, Z=0
Southern hemisphere : H=0, V=-520 mG, Z=0
Equatorial Support : H=0, V=0 mG, Z=0

4.4 All voltages are to be measured or applied with respect to ground.

Note: Do not use heatsink as ground.

4.5 Adjust function controls " " to center position except for contrast control which should be set to MAX.

4.6 Apply a video signal in the 1280 x 1024 with 64kHz/60Hz mode, select cross hatch pattern, set the Brightness for visible raster, adjust H-size for 340mm (19" monitor)/300mm (17" monitor) "raster width", adjust R3551 for Horizontal raster center.

5. To access factory mode:


- Turn off monitor (don't turn off PC)
 - Press " " and " " simultaneously on the front control panel, until the OSD menu with characters "factory mode (below OSD menu)" come on the screen of monitor.
 - If OSD menu disappears on the screen of monitor, press " " again (anytime), then the OSD menu comes on the screen again.
 - using " " : to select OSD menu.
 - : to increase or decrease the setting.
- (Please also refer to page 4, 5, 6 and 7 for OSD adjustment)

5.1. To leave factory mode

* After alignment of factory mode, turn off monitor (if you do not turn off monitor, the OSD menu is always at the factory mode), then turn on monitor again (at this moment, the OSD menu goes back to user mode).

6. OSD CONTROLS (During alignment)

During alignment, please use the "OSD controls" to keep OSD menu, or to shift OSD menu as below.



⊕ **TIMER** Set OSD display time, select "OFF", then the OSD menu will stay on the screen (won't disappear).

⬆ **VERTICAL POSITION** Move the OSD windows up or down.

⬅ **HORIZONTAL POSITION** Move the OSD window left or right.

Electrical Adjustments (Continued)

7. Alignment of Vg2 cut-off point, white tracking (OSD control)

Equipment : 1. Video Test Generator-801GC (Quantum Data)
2. Color-analyzer (Minolta CA-100)

VG2 [(screen), at the bottom of the L.O.T.].

* Apply a video signal in the 1024 x 768 with 69 kHz/85 Hz mode, select the "full white pattern".

* Use color-analyzer (Minolta CA-100) to adjust cutoff and white uniformity.

OSD R/G/B cut-off and R/G/B gain can be accessed, with initial data:

R cutoff = 50%, R gain = 70%
G cutoff = 50%, G gain = 70%
B cutoff = 50%, B gain = 70%

Step 1: To select the character "FACTORY MODE" as shown in Fig. 2.1, press " " to access the OSD menu for R/G/B gain & cutoff as shown in Fig. 2.2.

Step 2: Use " " to increase or decrease the value as shown in Fig. 2.3.






Fig. 2.3

7.1 Connect the video input, set brightness control at 50% and contrast at minimum position, Vg2 at Minimum (counter clockwise, and ABL (3647, potentiometer) at center position. Slowly increase Vg2 voltage until light output is at 0.17Ft-L +/- 0.05Ft-L (Y=0.17Ft-L, on the screen of CA-100).

7.2 (The screen of monitor is dark now)

: Press " " to show the OSD menu as shown in Fig. 2.1.
: Select the character "FACTORY MODE" to access the R/G/B adjustment as shown in Fig. 2.2 and Fig. 2.3.

: Adjust the cutoff of R/G/B to get 9300K
(x=0.281 +/- 0.015, y=0.311 +/- 0.015), and brightness output at 0.17 +/- 0.05 Ft-L (Y=0.17Ft-L).

7.3 : Press " " to set contrast at maximum (100%).

: Adjust gain of R/G/B to get 9300K
(x=0.281 +/- 0.015, y=0.311 +/- 0.015, don't care about the Y value)

7.4 Apply a small white square 60 x 60 mm pattern, or 8% fill of full screen, brightness set to center (50%), and contrast at maximum (100%), adjust gain control (OSD) to reach 34 +/- 2 Ft-L.

7.5 : Select the 6500K colour temperature as shown in Fig. 2.2.

: Adjust the R/G/B cutoff and R/G/B gain as shown in procedure 7.2-7.4 to get R/G/B cutoff

x= 0.313 +/- 0.015
y= 0.329 +/- 0.015
Y= 0.17 +/- 0.05 Ft-L
R/G/B gain x= 0.313 +/- 0.015
y= 0.329 +/- 0.015
Y= 30 +/- 2 Ft-L

7.6 : Select the 5500K colour temperature as shown in Fig. 2.2.
: Adjust the R/G/B cutoff & R/G/B gain as procedure 7.2-7.4

to get R/G/B cutoff x= 0.332 +/- 0.015
y= 0.347 +/- 0.015
Y= 0.17 +/- 0.05 Ft-L
R/G/B gain x= 0.332 +/- 0.015
y= 0.347 +/- 0.015
Y= 25 +/- 2 Ft-L

7.7 Apply full white pattern at 9300K, adjust ABL R3647 to reach 31 +/- 2 Ft-L (19") (contrast at maximum, brightness at center).
30 +/- 2 Ft-L (for 17" monitor).

8. Picture geometry setting (factory pre-set modes)

- Apply a video signal with cross-hatch pattern.
- Apply a video signal in the 1024 x 768 with 69 kHz/85 Hz mode.
- Set brightness and contrast controls to their center positions (OSD control).

8.1 Horizontal geometry (OSD control)

- Adjust the H-width to 340 mm (for 19" monitor).
300 mm (for 17" monitor).
- Adjust the H-phase to center position.

8.2 Vertical geometry (OSD control)

- Adjust vertical size to 255 mm (for 19" monitor).
225 mm (for 17" monitor).
- Adjust V-phase to center position.

8.3 Trapezoid distortion (OSD control)

- Adjust the trapezoid to get optimal vertical lines.

8.4 Pincushion (OSD control)

- Adjust the pincushion to get optimal vertical line.

8.5 Parallelogram (OSD control)

- Adjust parallelogram so that vertical lines are vertical or symmetrically about the center vertical axis.

8.6 Unbalance-pin (OSD control)

- Adjust the unbalance-pin so that that vertical border lines are aligned symmetrically.

8.7 Rotation (OSD control)

- Adjust picture so that vertical tilt is less than +/- 0.5mm.

8.8 Store the preset results by selecting the "exit" (OSD control).

8.9 Repeat the procedure 8.1 to 8.8 until all the preset timings have been adjusted completely

9. Focus adjustment

- : Apply a video signal in the 1024 x 768 with 69 kHz/85 Hz mode.
- : Select "ME" pattern.
- : Set the brightness at center (50%) and the contrast at maximum (100%).
- : Adjust focus potentiometers (top of L.O.T.) Focus 1 for horizontal focus and Focus 2 for vertical focus so that the picture at 2/3 of the diagonal lines (from center to four corners) of the displayed screen is as sharp as possible.

10. Loading DDC code



The DDC HEX data should be written into the DDC IC (7331) by EEPROM writer or equivalent method.

- a: Service DDC Kit
DDC Module (DDC cable), Part number = 4822 320 12004
DDCV2N.EXE software (3.5" disk), Part number = 4822 711 00004
- b: Please refer to Service information 4822 727 21995 for using the Service DDC Kit.

If you have Windows '95...

follow these steps to complete setting up your monitor.

1. Start Windows '95 and install CD ROM supplied with this monitor.
2. Click on the "START" icon. Next, click on the "SETTINGS" icon. Then click on "CONTROL PANEL."
3. Double-click on "DISPLAY" icon. Next, click on "SETTINGS" tab. Then click on "ADVANCED PROPERTIES" dialog box.
4. Click on "MONITOR" tab.
- 5.(a) If you have an old computer, click on "CHANGE" dialog box. Next, "SELECT DEVICE" screen appears. Now click on "HAVE DISK" dialog box. and select CD-ROM drive
Or
- 5.(b) If you have a new computer, "SELECT DEVICE" screen automatically appears. Click on "HAVE DISK" dialog box and select CD-ROM drive.
6. Select "OK" in the "INSTALL FROM DISK" dialog box. If model name of the Philips monitor is correct, click "OK" tab in the "SELECT DEVICE" dialog box.
7. Click "CLOSE" tab in the "ADVANCED PROPERTIES" dialog box. If your Windows'95 version is different or you need more detailed installation information, please refer to the windows '95 user's manual. **For additional information on the monitor, please refer to the owner's manual.**

**USB CONNECTIONS**

USB (Universal Serial Bus) is an innovation in connecting your IBM-compatible computer to your monitor. By using the USB, you will be able to connect your keyboard, mouse, printer, and other peripherals to your monitor instead of having to connect them to your computer. This will give you greater flexibility in setting up your system. Plus, you will have true plug-and-play capability. While the software is still being developed, Philips has included the hardware so you will be ready to take advantage of this next generation in computer development.

For an IBM-compatible Computer:

1. Turn off the computer.
2. Connect the (optional) USB Hub and cable to the computer and to the monitor. (Computer must have USB port.)
3. Connect the power cable.
4. Turn on the monitor. Then turn on the computer.
5. With the installation of the correct software, you will be able to connect specially-made peripherals to the monitor.

Note : USB Hub and cables sold separately. USB Bay exists in back of monitor.


Use the information file (philips.inf) for Windows '95 (Philips Monitors-Driver Disk)



Philips' monitors build in VESA DDC1/2B feature to support Plug & Play requirement for Windows'95. You can install this information file (philips.inf) in order to select your Philips monitor from "Monitor" dialog box in Windows 95 to activate Plug & Play application. The installation procedure based on Windows '95 OEM Release 2 is specified as follows,

1. Start Windows '95
2. Click the 'Start' button, point to 'Settings', and then click 'Control Panel'
3. Double-click the 'Display' icon, select the 'Settings' tab, then select "Advanced Properties" tab.
4. Select "Ok" in the "Install From Disk" dialog box.
5. Now, you can see the Philips monitor is appeared.
6. If the model name of Philips monitor is correct, click "Ok" tab in "Select Device" dialog box.
7. Then, click "Close" tab in "Advanced Properties" dialog box.
8. Now, you can select "Refresh Rate" to change monitor resolution


If your Windows'95 version is different or you need more detail installation information, please refer to Windows 95 user's manual.


Quick Reference for OSD Adjustment






Quick Reference for OSD Adjustment (Continued)








Quick Reference for OSD Adjustment (Continued)




continued)



Quick Reference for OSD Adjustment (Continued)




screen 67



push
back to screen 6


screen 7



push → exit OSD

rotate

screen 8




push

RESET ALL SETTINGS




NO YES

push

back to screen 1




"When rotary default setting selected"



Wiring diagram

19A CM5800

15



Mechanical Adjustments

0. Location of the panel

- 0.1 Main panel (1156)
- 0.2 Video panel (1157)
- 0.3 Earphone panel (1158)
- 0.4 Terminal panel (1159)
- 0.5 USB panel (1160) - optional
- 0.6 Encoder panel (1162)
- 0.7 Power switch panel (1163)

1. General

To be able to perform measurements and repairs on the circuit boards, the monitor should be placed in **Service Position** (Fig. 3.1) first:

How to remove the back cover of monitor :

There are 4 screws [2 screws are at the rear of the monitor, the other two screws are on the bottom of the monitor] to fix the front cabinet and back cover of the monitor.

Step 1: Remove the "cable cover" as shown in Fig. 3.2.

Step 2: Remove 2 screws (rear view) as shown in Fig. 3.3.

Step 3: Turn the set to remove the other 2 screws, as shown in Fig. 3.4 .

Step 4: Turn the set to its original position.

Step 5: Remove back cover (* There are two "plastic clips" on the "front cabinet" to hold the "rear cover" as shown in Fig. 3.5).

Chassis :

After removing the back cover, you can see the inside the monitor with metal frame and metal shield.

- Remove 26 screws for service position as Fig. 3.6 to Fig. 3.15.

Video panel :

- After removing the metal frames, remove the metal shielding on rear side of Video panel for measurement.

Main panel :

- After removing the metal frames,
- Disconnect "Video panel"
- Disconnect EHT cable (EHT cap)
- Disconnect 4 pin connector "M1501" (wire of YOKE, on Main panel)
- Disconnect 2 pin connector "M1114" (degaussing coil, on Main panel)
- Disconnect 1 pin connector "M1701" (on Video panel)
- Disconnect 2 pin connector "M1219" (on Main panel)
- Disconnect 9 pin connector "M1217" (on Main panel)
- Disconnect 3 pin connector "M1213" (on Main panel)
- Disconnect 3 pin connector "M1504" (on Main panel)
- Disconnect 2 pin connector "M1218" (on Main panel)
- Disconnect 2 pin connector "M1220" (on Main panel)
- Disconnect 7 pin connector "M1212" (on Main panel)
















- To slide out Main panel.
- Remove 2 screws as shown in Fig. 3.14, then push the clips to the right as shown in Fig. 3.13, to separate the bottom plate.
- Remove the plastic frame as shown in Fig. 3.15.
- Remove the "Rotary panel" "Earphone panel" from Front cabinet and place it on the table as shown in Fig. 3.1.
- Connect all the connectors and panels for service position.

Service position :







Place monitor in service position as shown in Fig. 3.1 through Fig. 3.15.

2. Repair instructions

After the service position is obtained, all the panel's copper trace sides may be accessed.




Block Diagram




Video Panel C.B.A. (A)

6703 B 3	3707 D 6	3749 C 2	2793 C 1	2743 B 2	1701 C 3
6704 D 2	3706 D 6	3750 D 2	3701 B 7	2744 B 3	1702 B 7
6705 B 3	3709 D 6	3751 C 2	3702 B 7	2745 A 2	1703 D 3
6706 D 1	3800 D 1	3752 D 5	3703 B 7	2746 A 1	1704 D 5
6708 D 5	3801 D 6	3753 C 2	3705 D 7	2747 E 2	1705 E 3
6709 D 2	3802 D 6	3754 B 5	3706 D 7	2748 A 7	1706 C 4
6711 B 5	3803 D 7	3755 A 5	3708 D 7	2749 C 6	2701 B 7
6712 C 5	3804 E 6	3756 A 3	3709 D 7	2751 C 6	2702 B 7
6713 C 6	3806 C 2	3757 A 3	3710 B 6	2752 C 6	2703 B 7
6714 B 5	3807 B 2	3758 A 3	3711 D 7	2753 C 6	2704 B 6
6721 B 5	3810 D 6	3760 B 5	3713 B 6	2755 C 7	2705 C 7
6724 B 5	3811 D 5	3761 A 3	3714 B 6	2756 E 6	2707 B 6
6731 A 5	3812 C 5	3762 B 3	3715 C 7	2757 D 1	2708 B 6
6734 A 5	3813 D 7	3763 B 3	3716 B 7	2758 C 6	2709 A 6
7701 C 7	3814 B 4	3764 D 1	3717 C 7	2759 D 6	2711 A 6
7702 C 6	3815 B 3	3765 B 3	3718 C 7	2760 E 4	2712 B 5
7703 D 7	3816 C 2	3766 B 3	3719 D 7	2761 E 4	2713 B 5
7704 E 7	3817 B 7	3767 C 2	3720 B 6	2762 E 4	2714 A 5
7705 B 5	3818 A 1	3768 D 2	3721 B 7	2763 E 3	2715 B 6
7706 B 5	3819 B 5	3769 C 4	3722 B 7	2764 E 3	2716 B 5
7707 A 5	3820 B 5	3770 C 2	3723 B 7	2765 E 3	2717 A 4
7708 A 2	3821 A 5	3771 B 2	3724 A 7	2766 E 3	2718 A 4
7709 C 2	3822 A 5	3772 A 5	3725 A 7	2767 E 4	2719 A 4
7711 C 2	3823 A 5	3773 A 5	3726 A 7	2768 E 2	2720 B 2
7716 B 2	3824 A 5	3774 A 3	3727 B 6	2769 E 3	2721 B 4
7717 C 2	3825 B 5	3775 A 2	3728 A 6	2770 E 3	2722 B 3
7723 B 1	3826 A 5	3776 A 2	3729 B 6	2771 E 3	2723 B 4
7724 C 1	3827 A 5	3777 A 5	3730 B 6	2772 C 3	2724 A 5
7725 E 6	3828 E 6	3778 A 2	3731 A 6	2773 D 5	2725 B 5
7726 E 1	3829 C 5	3779 B 2	3732 A 6	2774 C 5	2726 B 5
7727 A 1	3831 C 6	3780 B 2	3733 A 6	2776 E 4	2727 A 3
	3832 C 6	3781 B 3	3734 A 6	2777 D 5	2728 A 3
		3782 B 1	3735 A 6	2778 D 2	2729 A 3
		3784 B 2	3736 B 5	2779 C 4	2730 B 3
		3785 C 1	3737 B 5	2780 C 3	2731 B 3
		3786 D 1	3738 A 4	2781 D 1	2732 B 3
		3787 C 3	3739 A 4	2782 E 1	2733 D 2
		3788 C 1	3740 B 5	2783 E 2	2734 A 5
		3789 C 1	3741 A 3	2784 C 2	2735 A 5
		3790 A 5	3742 B 5	2785 C 1	2736 A 5
		3791 E 6	3743 A 3	2786 C 1	2737 B 7
		3792 E 6	3744 B 4	2787 A 4	2738 A 3
		3793 D 6	3745 B 4	2788 A 3	2739 A 2
		3794 C 6	3746 D 2	2789 A 2	2740 A 2
		3795 C 6	3747 B 4	2791 D 2	2741 A 6
		3796 D 6	3748 B 4	2792 C 2	2742 B 2




Power Switch Panel C.B.A. (G)



Earphone Panel C.B.A. (F)

8033 A 3	5084 A 1	3085 A 4	3081 A 3	2084 A 4	1032 A 1
	6084 A 4	3093 A 1	3082 A 3	2085 A 4	1033 A 2
	8031 A 2	3094 A 1	3083 A 4	2086 A 3	2081 A 4
	9032 A 3	5083 A 1	3084 A 4	2087 A 3	2082 A 3





Power Switch Panel C.B.A. (G)





Terminal Panel C.B.A. (A1)

19A CM5800



















































17



Earphone Panel C.B.A. (F)






Waveforms for Diagram A1 and A2





Video Schematic Diagram

A2












U-CTRL Schematic Diagram


B3
























Waveforms for Diagram B2 and B3




Deflection Schematic Diagram




(s) : stands for SMD components

B2**B43 7605-C**0.2 V/div AC
5 μ S/div**B50 7632-G**5 V/div AC
5 μ S/div**B57 7647-B**5 V/div AC
5 mS/div**B44 7603-E**2 V/div AC
5 μ S/div**B51 7632-D**50 V/div AC
5 μ S/div**B58 7647-E**2 V/div AC
5 mS/div**B45 7601-3**0.2 V/div AC
5 μ S/div**B52 5638-9**100 V/div AC
5 μ S/div**B59 7522-E**5 V/div AC
5 μ S/div**B46 7601-4**10 V/div AC
5 μ S/div**B53 5638-3**100 V/div AC
5 μ S/div**B60 7523-G**5 V/div AC
5 μ S/div**B47 7601-6**5 V/div AC
5 μ S/div**B54 5638-1**100 V/div AC
5 μ S/div**B61 7523-D**50 V/div AC
5 μ S/div**B48 7633-G**5 V/div AC
5 μ S/div**B55 7634-G**5 V/div AC
5 μ S/div**B62 5522-6**2 V/div AC
5 μ S/div**B49 7633-D**5 V/div AC
5 μ S/div**B56 5638-8**5 V/div AC
5 μ S/div**B63 5522-7**0.5 V/div AC
5 μ S/div




Waveforms for Diagram C




[illegible]


Main Panel C.B.A. (B1, B2, B3, C and D)




C22 7111-18

2 V/div AC
5 uS/div


C29 7144-5

1 V/div AC
5 uS/div


C36 5161-1

5 V/div AC
5 uS/div


C43 7172-4

1 V/div AC
10 uS/div


C23 3147

5 V/div AC
5 uS/div


C30 7144-6

1 V/div AC
5 uS/div


C37 5161-5

0.5 V/div AC
5 uS/div


C24 7144-4

5 V/div AC
5 uS/div


C31 7146-7

0.1 V/div AC
5 uS/div


C38 7162-D

100 V/div AC
5 uS/div


C25 7144-2

5 V/div AC
5 uS/div


C32 7146-1

1 V/div AC
10 uS/div

C39 7168-G

5 V/div AC
5 uS/div


C26 7144-1

5 V/div AC
5 uS/div


C33 7146-3

0.2 V/div AC
10 uS/div

C40 7168-D

100 V/div AC
5 uS/div


C27 7144-10

5 V/div AC
5 uS/div


C34 7146-2

0.2 V/div AC
10 uS/div


C41 5162-11

50 V/div AC
5 uS/div


C28 7144-13

5 V/div AC
5 uS/div

C35 5161-1

5 V/div AC
5 uS/div

C42 5162-12



50 V/div AC
5 uS/div

0138 B 7	7363 Z 2	0136 J 13	9587 D 2	8448 E 3	8221 C 2	2051 D 18	2260 K 3	1181 L 15
0131 H 8	7394 Z 2	0139 H 13	9588 D 2	8449 E 3	8222 C 2	2052 D 18	2261 K 3	1182 L 14
0122 H 6	7395 J 1	0130 H 13	9589 D 2	8450 E 3	8223 C 2	2053 D 18	2262 K 3	1183 L 15
0133 H 8	7396 J 2	0140 H 15	9590 J 3	8451 F 2	8224 C 2	2054 D 18	2263 K 3	1184 L 15
0134 K 8	7397 J 2	0141 L 16	9591 J 3	8452 F 2	8225 C 2	2055 D 18	2264 K 3	1185 L 15
0135 H 8	7398 J 2	0142 L 16	9592 J 3	8453 F 2	8226 C 2	2056 D 18	2265 K 3	1186 L 15
0136 I 8	7399 J 2	0143 L 16	9593 J 3	8454 F 2	8227 C 2	2057 D 18	2266 K 3	1187 L 15
0137 H 15	7400 F 4	0144 K 7	9594 J 3	8455 F 2	8228 C 2	2058 D 18	2267 K 3	1188 L 15
0138 E 8	7401 F 4	0145 K 7	9595 J 3	8456 F 2	8229 C 2	2059 D 18	2268 K 3	1189 L 15
0139 D 8	7402 F 4	0146 K 7	9596 J 3	8457 F 2	8230 C 2	2060 D 18	2269 K 3	1190 L 15
0140 D 8	7403 F 4	0147 K 7	9597 J 3	8458 F 2	8231 C 2	2061 D 18	2270 K 3	1191 L 15
0141 G 8	7404 F 4	0148 K 7	9598 J 3	8459 F 2	8232 C 2	2062 D 18	2271 K 3	1192 L 15
0142 G 8	7405 F 4	0149 K 7	9599 J 3	8460 F 2	8233 C 2	2063 D 18	2272 K 3	1193 L 15
0143 G 8	7406 F 4	0150 K 7	9600 J 3	8461 F 2	8234 C 2	2064 D 18	2273 K 3	1194 L 15
0144 F 8	7407 F 4	0151 K 7	9601 J 3	8462 F 2	8235 C 2	2065 D 18	2274 K 3	1195 L 15
0145 F 8	7408 F 4	0152 K 7	9602 J 3	8463 F 2	8236 C 2	2066 D 18	2275 K 3	1196 L 15
0146 G 8	7409 F 4	0153 K 7	9603 J 3	8464 F 2	8237 C 2	2067 D 18	2276 K 3	1197 L 15
0147 G 8	7410 F 4	0154 K 7	9604 J 3	8465 F 2	8238 C 2	2068 D 18	2277 K 3	1198 L 15
0148 H 8	7411 F 4	0155 K 7	9605 J 3	8466 F 2	8239 C 2	2069 D 18	2278 K 3	1199 L 15
0149 H 8	7412 F 4	0156 K 7	9606 J 3	8467 F 2	8240 C 2	2070 D 18	2279 K 3	1200 L 15
0150 H 8	7413 F 4	0157 K 7	9607 J 3	8468 F 2	8241 C 2	2071 D 18	2280 K 3	1201 L 15
0151 H 8	7414 F 4	0158 K 7	9608 J 3	8469 F 2	8242 C 2	2072 D 18	2281 K 3	1202 L 15
0152 H 8	7415 F 4	0159 K 7	9609 J 3	8470 F 2	8243 C 2	2073 D 18	2282 K 3	1203 L 15
0153 H 8	7416 F 4	0160 K 7	9610 J 3	8471 F 2	8244 C 2	2074 D 18	2283 K 3	1204 L 15
0154 H 8	7417 F 4	0161 K 7	9611 J 3	8472 F 2	8245 C 2	2075 D 18	2284 K 3	1205 L 15
0155 H 8	7418 F 4	0162 K 7	9612 J 3	8473 F 2	8246 C 2	2076 D 18	2285 K 3	1206 L 15
0156 H 8	7419 F 4	0163 K 7	9613 J 3	8474 F 2	8247 C 2	2077 D 18	2286 K 3	1207 L 15
0157 H 8	7420 F 4	0164 K 7	9614 J 3	8475 F 2	8248 C 2	2078 D 18	2287 K 3	1208 L 15
0158 H 8	7421 F 4	0165 K 7	9615 J 3	8476 F 2	8249 C 2	2079 D 18	2288 K 3	1209 L 15
0159 H 8	7422 F 4	0166 K 7	9616 J 3	8477 F 2	8250 C 2	2080 D 18	2289 K 3	1210 L 15
0160 H 8	7423 F 4	0167 K 7	9617 J 3	8478 F 2	8251 C 2	2081 D 18	2290 K 3	1211 L 15
0161 H 8	7424 F 4	0168 K 7	9618 J 3	8479 F 2	8252 C 2	2082 D 18	2291 K 3	1212 L 15
0162 H 8	7425 F 4	0169 K 7	9619 J 3	8480 F 2	8253 C 2	2083 D 18	2292 K 3	1213 L 15
0163 H 8	7426 F 4	0170 K 7	9620 J 3	8481 F 2	8254 C 2	2084 D 18	2293 K 3	1214 L 15
0164 H 8	7427 F 4	0171 K 7	9621 J 3	8482 F 2	8255 C 2	2085 D 18	2294 K 3	1215 L 15
0165 H 8	7428 F 4	0172 K 7	9622 J 3	8483 F 2	8256 C 2	2086 D 18	2295 K 3	1216 L 15
0166 H 8	7429 F 4	0173 K 7	9623 J 3	8484 F 2	8257 C 2	2087 D 18	2296 K 3	1217 L 15
0167 H 8	7430 F 4	0174 K 7	9624 J 3	8485 F 2	8258 C 2	2088 D 18	2297 K 3	1218 L 15
0168 H 8	7431 F 4	0175 K 7	9625 J 3	8486 F 2	8259 C 2	2089 D 18	2298 K 3	1219 L 15
0169 H 8	7432 F 4	0176 K 7	9626 J 3	8487 F 2	8260 C 2	2090 D 18	2299 K 3	1220 L 15
0170 H 8	7433 F 4	0177 K 7	9627 J 3	8488 F 2	8261 C 2	2091 D 18	2300 K 3	1221 L 15
0171 H 8	7434 F 4	0178 K 7	9628 J 3	8489 F 2	8262 C 2	2092 D 18	2301 K 3	1222 L 15
0172 H 8	7435 F 4	0179 K 7	9629 J 3	8490 F 2	8263 C 2	2093 D 18	2302 K 3	1223 L 15
0173 H 8	7436 F 4	0180 K 7	9630 J 3	8491 F 2	8264 C 2	2094 D 18	2303 K 3	1224 L 15
0174 H 8	7437 F 4	0181 K 7	9631 J 3	8492 F 2	8265 C 2	2095 D 18	2304 K 3	1225 L 15
0175 H 8	7438 F 4	0182 K 7	9632 J 3	8493 F 2	8266 C 2	2096 D 18	2305 K 3	1226 L 15
0176 H 8	7439 F 4	0183 K 7	9633 J 3	8494 F 2	8267 C 2	2097 D 18	2306 K 3	1227 L 15
0177 H 8	7440 F 4	0184 K 7	9634 J 3	8495 F 2	8268 C 2	2098 D 18	2307 K 3	1228 L 15
0178 H 8	7441 F 4	0185 K 7	9635 J 3	8496 F 2	8269 C 2	2099 D 18	2308 K 3	1229 L 15
0179 H 8	7442 F 4	0186 K 7	9636 J 3	8497 F 2	8270 C 2	2100 D 18	2309 K 3	1230 L 15
0180 H 8	7443 F 4	0187 K 7	9637 J 3	8498 F 2	8271 C 2	2101 D 18	2310 K 3	1231 L 15
0181 H 8	7444 F 4	0188 K 7	9638 J 3	8499 F 2	8272 C 2	2102 D 18	2311 K 3	1232 L 15
0182 H 8	7445 F 4	0189 K 7	9639 J 3	8500 F 2	8273 C 2	2103 D 18	2312 K 3	1233 L 15
0183 H 8	7446 F 4	0190 K 7	9640 J 3	8501 F 2	8274 C 2	2104 D 18	2313 K 3	1234 L 15
0184 H 8	7447 F 4	0191 K 7	9641 J 3	8502 F 2	8275 C 2	2105 D 18	2314 K 3	1235 L 15
0185 H 8	7448 F 4	0192 K 7	9642 J 3	8503 F 2	8276 C 2	2106 D 18	2315 K 3	1236 L 15
0186 H 8	7449 F 4	0193 K 7	9643 J 3	8504 F 2	8277 C 2	2107 D 18	2316 K 3	1237 L 15
0187 H 8	7450 F 4	0194 K 7	9644 J 3	8505 F 2	8278 C 2	2108 D 18	2317 K 3	1238 L 15
0188 H 8	7451 F 4	0195 K 7	9645 J 3	8506 F 2	8279 C 2	2109 D 18	2318 K 3	1239 L 15
0189 H 8	7452 F 4	0196 K 7	9646 J 3	8507 F 2	8280 C 2	2110 D 18	2319 K 3	1240 L 15
0190 H 8	7453 F 4	0197 K 7	9647 J 3	8508 F 2	8281 C 2	2111 D 18	2320 K 3	1241 L 15
0191 H 8	7454 F 4	0198 K 7	9648 J 3	8509 F 2	8282 C 2	2112 D 18	2321 K 3	1242 L 15
0192 H 8	7455 F 4	0199 K 7	9649 J 3	8510 F 2	8283 C 2	2113 D 18	2322 K 3	1243 L 15
0193 H 8	7456 F 4	0200 K 7	9650 J 3	8511 F 2	8284 C 2	2114 D 18	2323 K 3	1244 L 15
0194 H 8	7457 F 4	0201 K 7	9651 J 3	8512 F 2	8285 C 2	2115 D 18	2324 K 3	1245 L 15
0195 H 8	7458 F 4	0202 K 7	9652 J 3	8513 F 2	8286 C 2	2116 D 18	2325 K 3	1246 L 15
0196 H 8	7459 F 4	0203 K 7	9653 J 3	8514 F 2	8287 C 2	2117 D 18	2326 K 3	1247 L 15
0197 H 8	7460 F 4	0204 K 7	9654 J 3	8515 F 2	8288 C 2	2118 D 18	2327 K 3	1248 L 15
0198 H 8	7461 F 4	0205 K 7	9655 J 3	8516 F 2	8289 C 2	2119 D 18	2328 K 3	1249 L 15
0199 H 8	7462 F 4	0206 K 7	9656 J 3	8517 F 2	8290 C 2	2120 D 18	2329 K 3	1250 L 15
0200 H 8	7463 F 4	0207 K 7	9657 J 3	8518 F 2	8291 C 2	2121 D 18	2330 K 3	1251 L 15
0201 H 8	7464 F 4	0208 K 7	9658 J 3	8519 F 2	8292 C 2	2122 D 18	2331 K 3	1252 L 15
0202 H 8	7465 F 4	0209 K 7	9659 J 3	8520 F 2	8293 C 2	2123 D 18	2332 K 3	1253 L 15
0203 H 8	7466 F 4	0210 K 7	9660 J 3	8521 F 2	8294 C 2	2124 D 18	2333 K 3	1254 L 15
0204 H 8	7467 F 4	0211 K 7	9661 J 3	8522 F 2	8295 C 2	2125 D 18	2334 K 3	1255 L 15
0205 H 8	7468 F 4	0212 K 7	9662 J 3	8523 F 2	8296 C 2	2126 D 18	2335 K 3	1256 L 15
0206 H 8	7469 F 4	0213 K 7	9663 J 3	8524 F 2	8297 C 2	2127 D 18	2336 K 3	1257 L 15
0207 H 8	7470 F 4	0214 K 7	9664 J 3	8525 F 2	8298 C 2	2128 D 18	2337 K 3	12


USB Schematic Diagram (Optional)

19A CM5800

25




E01 1082-1




0.1 V/div AC
10 uS/div

E02 1083-1




0.1 V/div AC
10 uS/div


Audio Schematic Diagram



Earphone Schematic Diagram





Rotary Schematic Diagram




Rotary Schematic Diagram

Power Switch Schematic Diagram


G



1199 B 4
1248 C C 3
1249 A A 3
1293 D D 3
6291 B B 3
8199 C C 6
8199 C C 6
8199 B B 6
8249 B A 1
8249 A A 1
8249 D D 1
8249 D D 1
8249 C C 1
8249 C C 1
8249 B B 1



Rotary Panel C.B.A. (G)



Warning

All ICs and many other semiconductors are susceptible to electrostatic discharges (ESD). Careless handling during repair can reduce life drastically. When repairing, make sure that you are connected with the same potential as the mass of the unit via a wrist wrap with resistance. Keep components and tools also at the same potential.

1. Servicing of SMDs (Surface Mounted Devices)

- 1.1 General cautions on handling and storage
- Oxidation on the terminals of SMDs results in poor soldering. Do not handle SMDs with bare hands.
 - Avoid using storage places that are sensitive to oxidation such as places with sulphur or chlorine gas, direct sunlight, high temperatures or a high degree of humidity. The capacitance or resistance value of the SMDs may be affected by this.
 - Rough handling of circuit boards containing SMDs may cause damage to the components as well as the circuit boards. Circuit boards containing SMDs should never be bent or flexed. Different circuit board materials expand and contract at different rates when heated or cooled and the components and/or solder connections may be damaged due to the stress. Never rub or scrape chip components as this may cause the value of the component to change. Similarly, do not slide the circuit board across any surface.

1.2 Removal of SMDs

- Heat the solder (for 2-3 seconds) at each terminal of the chip. By using a solder wick and a slight horizontal force, small components can be removed with the soldering iron. They can also be removed with a solder sucker (see Fig. 4.1A)




Fig. 4.1

- While holding the SMD with a pair of tweezers, take it off gently using the soldering iron's heat applied to each terminal (see Fig. 4.1 B).
- Remove the excess solder on the solder lands by means of a solder wick or a solder sucker (see Fig. 4.1C).

- 1.3 Caution on removal
- When handling the soldering iron, use suitable pressure and be careful.
 - When removing the chip, do not use undue force with the pair of tweezers.
 - The soldering iron to be used (approx. 30 W) should preferably be equipped with a thermal control (soldering temperature: 225 to 250 °C).
 - The chip, once removed, must never be reused.

1.4 Attachment of SMDs

- Locate the SMD on the solder lands by means of tweezers and solder the component on one side. Ensure that the component is positioned correctly on the solder lands (see Fig. 4.2A).
- Next complete the soldering of the terminals of the component (see Fig. 4.2B).




Fig. 4.2

2. Caution when attaching SMDs

- When soldering the SMD terminals, do not touch them directly with the soldering iron. The soldering should be done as quickly as possible, care must be taken to avoid damage to the terminals of the SMDs themselves.
- Keep the SMD's body in contact with the printed board when soldering.
- The soldering iron to be used (approx. 30 W) should preferably be equipped with a thermal control (soldering temperature: 225 to 250 °C).
- Soldering should not be done outside the solder land.
- Soldering flux (of rosin) may be used, but should not be acidic.
- After soldering, let the SMD cool down gradually at room temperature.
- The quantity of solder must be proportional to the size of the solder land. If the quantity is too great, the SMD might crack or the solder lands might be torn loose from the printed board (see Fig. 4.3).

EXAMPLES






Fig. 4.3



Exploded View



**Parts indicated on
exploded view:
Model: 19A580BQ/74C**

1156 Main panel

Various

Various

29

2450	4822	124	40246	4.7 μ F 20% 63V
------	------	-----	-------	---------------------

29

3181 4822 05

30

W	2222	1822	051	20472	447.5%	0.1W
---	------	------	-----	-------	--------	------

Spare parts list

3595A 4822 052 11689 6811 5% 0.5W

Spare parts list

19A580BQ/74C 31

3605	4822 050 22709	27Ω 1% 0.6W	5525	4822 157 71372	CHOCK COIL 20μH	6534	4822 130 63612	BY459-1500	7466	4822 130 42513	BC858C
3606	4822 116 82967	68k 0.125	5526	3138 128 78450	LINEARITY COIL	6535	4822 130 34197	BZX79-B12	7467	4822 130 42513	BC858C
3607	4822 117 12581	82k 5% 0.5W	5583	4822 152 20596	IND FXD SP0305 A	6539	4822 130 11114	BYM26B	7468	4822 130 10829	MUN2211J
3608	4822 051 20154	150k 5% 0.1W	5632	4822 157 71372	CHOCK COIL	6542	4822 130 30621	1N4148	7470	4822 130 10829	MUN2211J
3609	4822 050 20104	4k7 5% 0.1W	5638*	3138 128 78760	LINE OUTPUT TRANSFORMER	6548	4822 130 31607	RGP10D	7471	5322 130 60068	BC558C
3611	4822 117 12584	820Ω 1%	5651	4822 146 10738	DAF TRANSFORMER	6549	4822 130 31607	RGP10D	7472	4822 130 41646	BF423
3612	4822 051 20302	3k 5% 0.1W	5625	4822 157 63218	DRUM COIL 10 mH	6601	4822 130 31607	RGP10D	7473	4822 130 41782	BF422
3613	4822 050 22201	220Ω 1% 0.6W	6111	4822 130 80572	RCP30J	6603	4822 130 31607	RGP10D	7474	5322 209 66254	NES532N
3614	4822 050 21803	18k 1% 0.6W	6112	5322 130 10709	BYM26C	6605	4822 130 80446	BAS32L	7475	5322 130 60068	BC558C
3615	4822 050 21803	18k 1% 0.6W	6114	4822 130 80446	BAS32L	6606	4822 130 30621	1N4148	7488	4822 130 41594	PH2369
3616	4822 050 21003	10k 1% 0.6W	6115	4822 130 31607	RGP10D	6607	4822 130 30621	1N4148	7489	4822 130 10829	MUN2211J
3617	4822 050 11002	1k 1% 0.4W	6116	4822 130 34173	BZX79-B5V6	6608	4822 130 80446	BAS32L	7490	5322 130 60068	BC558C
3618	4822 117 10834	47k 1% 0.1W	6130	4822 130 34488	BZX79-B11	6611	4822 130 34233	BZX79-B5V1	7491	5322 209 61472	LM338M
3619	4822 050 21004	100k 1% 0.6W	6131	4822 130 34488	BZX79-B11	6613	4822 130 80446	BAS32L	7501	4822 492 62076	FOR TRANSISTORS
3620	4822 050 25603	56k 1% 0.6W	6132	4822 130 10742	UF4004	6617	4822 130 80446	BAS32L	7502	4822 130 44196	BC548C
3621	4822 050 25103	51k 1% 0.6W	6133	4822 130 10742	UF4004	6618	4822 130 80446	BAS32L	7512	4822 130 44196	BC548C
3622	4822 100 11213	22k 30%lin 0.1W	6134	4822 130 30621	1N4148	6626	4822 130 31393	BYT52J	7521	4822 130 44196	BC548C
3623*	4822 050 10478	407 5% 0.35W	6135	5322 130 80282	P6KE180A	6632	4822 130 83128	EGP30G	7522	5322 130 60068	BC558C
3624	4822 051 20102	1k 5% 0.1W	6136	4822 130 32343	BYV26C	6638	4822 130 30621	1N4148	7523	4822 130 63081	BSN254A
3625	4822 050 22202	2k2 1% 0.6W	6138	5322 130 81917	SB140	6642	4822 130 34085	BZX79-B75	7532	4822 130 11116	BU2532AL
3626	4822 050 10478	407 5% 0.33W	6139	5322 130 81917	SB140	6655	4822 130 60815	BYV26E	7532	4822 492 62076	FOR TRANSISTORS
3627	4822 050 21005	1M 1% 0.6W	6140	4822 130 32715	SB340	6656	5322 130 32274	BY584	7541	4822 130 44196	BC548C
3630	4822 053 21224	220k 5% 0.5W	6141	4822 130 34173	BZX79-B5V6	6657	5322 130 32274	BY584	7543	4822 130 10788	MTF6P25
3631	4822 117 11622	270k 5% 0.5W	6142	4822 130 30621	1N4148	6675	4822 130 30621	1N4148	7550	4822 130 63274	2SC2344E
3632	4822 117 11631	39Ω 5% 2W	6143	4822 130 30621	1N4148	6676	4822 130 34233	BZX79-B5V1	7551	4822 130 63275	2SA1011E
3633	4822 050 21003	10k 1% 0.6W	6145	4822 130 80446	BAS32L	6677	4822 130 30621	1N4148	7555	4822 209 70672	LM358N SEL.
3634*	4822 052 11109	10Ω 5% 0.5W	6146	4822 130 30682	BZX79-B9V1	6678	4822 130 34233	BZX79-B5V1	7556	4822 130 40823	BD139
3635	4822 050 24701	470Ω 1% 0.6W	6161	4822 130 34489	BZX79-B20	7131	4822 209 16121	L4981A	7557	4822 130 40824	BD140
3636*	4822 052 11628	82Ω 5% 0.5W	6162	4822 130 10742	UF4004	7112	4822 130 11117	STU14NA50	7576	4822 209 18098	M02393P
3637	4822 050 21001	100Ω 1% 0.6W	6167	4822 130 34499	BZX79-B20	5322 390 20011	VET SILIC.P4	20GR	7591	4822 209 70672	LM358N SEL.
3638	4822 050 24701	470Ω 1% 0.6W	6170	4822 130 10742	UF4004	7133	4822 130 34197	BZX79-B12	7592	4822 130 41053	BC639
3639	4822 050 21003	10k 1% 0.6W	6172	4822 130 10742	UF4004	7134	4822 130 10829	MUN2211J	7593	4822 130 41087	BC638
3640*	4822 117 10442	10Ω 5%	6173	4822 130 10742	UF4004	7144	4822 209 16097	L4990	7601	4822 209 33432	UC3842BN
3641	4822 050 21201	120Ω 1% 0.6W	6174	4822 130 10742	UF4004	7145	4822 209 70672	LM358N SEL.	7602	4822 209 70672	LM358N SEL.
3642	4822 050 18204	820k 1% 0.4W	6176	4822 130 10742	UF4004	7162	4822 130 10831	STP10NA40	7603	5322 130 42756	BC857C
3643	4822 050 28203	82k 1% 0.6W	6181	5322 130 10709	BYM26C	7168	4822 130 10631	STP10NA40	7604	4822 130 44196	BC548C
3644	4822 100 11382	47k 30%lin 0.1W	6182	4822 130 11113	31DF4-FC5	5322 390 20011	VET SILIC.P4	20GR	7605	5322 130 42756	BC857C
3645	4822 053 21104	100k 5% 0.5W	6183	4822 130 11113	31DF4-FC5	7172	4822 130 80908	CHX62A	7632	5322 130 63002	IRF640
3646	4822 117 11635	1k 0.5W	6184	4822 130 11113	31DF4-FC5	7181	4822 209 81276	MC7812CT	7633	4822 130 63081	BSN254A
3647	4822 100 11585	22k 30%LIN 0.1W	6186	4822 130 10835	UG4B	5322 390 20011	VET SILIC.P4	20GR	7634	4822 130 63445	MTF6N60
3648	4822 117 10833	10k 1% 0.1W	6188	4822 130 83909	BYW96-200RL	7189	4822 209 81397	TL431CLPST	5322 390 20011	VET SILIC.P4	20GR
3649	4822 050 22702	2k7 1% 0.6W	6189	4822 130 10742	UF4004	7201	4822 209 81397	TL431CLPST	7647	4822 130 44196	BC548C
3650	4822 050 25602	56k 1% 0.6W	6190	4822 130 83909	BYW96-200RL	7186	4822 209 81397	TL431CLPST	7651	4822 130 70025	BUX87P
3651	4822 053 21204	220k 5% 0.5W	6191	4822 130 80446	BAS32L	7187	4822 130 10829	MUN2211J	7652	4822 130 44196	BC548C
3652	4822 111 50617	2k2 10% 0.5W	6192	4822 130 31982	BYV27-100	7188	5322 130 60068	BC558C	7653	4822 130 44196	BC548C
3653	4822 053 21104	100k 5% 0.5W	6193	4822 130 30621	1N4148	7202	5322 209 11586	PC74HC14P	7671	5322 130 63002	IRF640
3654	4822 117 10833	10k 1% 0.1W	6194	4822 130 30621	1N4148	7257	5322 130 60068	BC558C	5322 390 20011	VET SILIC.P4	20GR
3655	4822 053 21155	1M5 5% 0.5W	6195	4822 130 31173	GP15D	7258	4822 130 44196	BC548C	7672	5322 130 63002	IRF640
3656	4822 052 21155	1M5 5% 0.5W	6196	4822 130 80446	BAS32L	7281	4822 130 44503	BC547C	5322 390 20011	VET SILIC.P4	20GR
3657	4822 050 21502	1k5 1% 0.6W	6197	4822 130 30621	1N4148	7282	4822 130 44503	BC547C	7673	5322 130 60684	IRF540
3658	4822 050 21003	10k 1% 0.6W	6201	5322 130 34337	BAV99	7301	5322 209 11109	74HC174N	7674	5322 130 60684	IRF540
3659	4822 050 11002	1k 1% 0.4W	6202	4822 130 80446	BAS32L	7302	4822 130 44196	BC548C	7675	5322 130 60684	IRF540
3660	4822 050 22903	39k 1% 0.6W	6203	4822 130 80446	BAS32L	7304	4822 130 10829	MUN2211J	7681	4822 130 10829	MUN2211J
3661	4822 050 24701	470Ω 1% 0.6W	6220	4822 130 80446	BAS32L	7305	5322 130 42136	BC848C	7682	4822 130 10829	MUN2211J
3662	4822 051 20223	22k 5% 0.1W	6221	5322 130 31504	BZX79-B3V3	7317	5322 130 42136	BC848C	7684	4822 130 10829	MUN2211J
3663	4822 117 11445	240k 5% 0.1W	6243	4822 130 80446	BAS32L	7318	4822 209 73852	PMBT2369	7685	4822 130 10829	MUN2211J
3664	4822 050 21505	1M5 5% 0.5W	6244	4822 130 80446	BAS32L	7319	4822 209 73852	PMBT2369	7708	4822 209 15329	CR6927
3665	4822 117 10833	10k 1% 0.1W	6255	4822 130 80446	BAS32L	7329	4822 130 44196	BC548C	5322 390 20011	VET SILIC.P4	20GR
3666	4822 050 21003	10k 1% 0.6W	6256	4822 130 30621	1N4148	7331	4822 209 15121	ST24LC21B1	7726	4822 209 33083	L7808CV
3668	4822 050 21003	10k 1% 0.6W	6281	4822 130 30621	1N4148	7401	4822 209 15123	TD4A858	5322 390 20011	VET SILIC.P4	20GR
3669	4822 050 21003	10k 1% 0.6W	6282	4822 130 30621	1N4148	7402	5322 130 42136	BC848C	7727	5322 209 85913	MC7912CT
3904	4822 116 40144	12Ω	6425	4822 130 30621	1N4148	7426	4822 130 44196	BC548C	4822 526 10544	FERRITE BEAD	
3907	4822 116 21237	1M A/100V	6473	4822 130 34328	BZX79-B30	7430	5322 130 42136	BC848C	7911	4822 130 44104	BC328
3912	4822 051 20472	4k7 5% 0.1W	6474	4822 130 80446	BAS32L	7431	4822 130 42513	BC858C	7912	4822 130 10829	MUN2211J
3913	4822 117 11449	2k2 1% 0.1W	6485	4822 130 34233	BZX79-B5V1	7443	4822 130 44196	BC548C			
3914	4822 050 21009	10Ω 1% 0.6W	6487	4822 130 80446	BAS32L	7444	4822 130 44196	BC548C			
			6491	4822 130 30621	1N4148	7445	4822 130 44196	BC548C			
			6493	4822 130 80446	BAS32L	7446	4822 130 44196	BC548C			
			6494	4822 130 30621	1N4148	7447	4822 130 44196	BC548C			
			6495	4822 130 30621	1N4148	7448	4822 130 44196	BC548C			
			6496	4822 130 30621	1N4148						
			6497	4822 130 30621	1N4148						
			6501	5322 130 31969	RGP15M						
			6511	4822 130 80446	BAS32L						
			6519	4822 130 80446	BAS32L						
			6526	4822 130 31607	RGP10D						
			6527	4822 130 42489	BYD33G						
			6531	5322 130 32184	BYV27-50						
			6401	4822 130 30621	1N4148						
			6425	4822 130 30621	1N4148						
			6473	4822 130 34328	BZX79-B30						
			6474	4822 130 80446	BAS32L						
			6485	4822 130 34233	BZX79-B5V1						
			6487	4822 130 80446	BAS32L						
			6491	4822 130 30621	1N4148						

Spare parts list

5322 360 20011	VET SIUC.P4 20GR
3136 126 78420	CRT SOCKET
-II-	
1702	4822 265 41419 6P
1705	4822 267 10702 14P MALE (63461B)
1706	4822 255 10379 HPS0720-011100
-II-	
2701	4822 126 13196 CER2 SMD 25V 100N PM10 R
2702	4822 126 13196 CER2 SMD 25V 100N PM10 R
2703	4822 126 13196 CER2 SMD 25V 100N PM10 R
2704	4822 126 13196 CER2 SMD 25V 100N PM10 R
2707	4822 126 13196 CER2 SMD 25V 100N PM10 R
2708	4822 126 13196 CER2 SMD 25V 100N PM10 R
2709	4822 126 13196 CER2 SMD 25V 100N PM10 R
2711	4822 126 13196 CER2 SMD 25V 100N PM10 R
2712	4822 122 33216 270pF 5% 50V
2713	4822 126 13196 CER2 SMD 25V 100N PM10 R
2714	4822 124 42171 22uF 25V
2715	4822 122 32504 15pF 2% 63V
2716	4822 126 13196 CER2 SMD 25V 100N PM10 R
2718	5322 122 32966 39pF 5% 50V
2719	5322 122 32448 10pF 5% 50V
2720	4822 124 81071 22uF 20% 160V
2721	4822 121 42004 10nF 10% 400V
2722	4822 126 14122 8.8nF 10% 50V
2723	4822 124 80606 1uF 20% 160V
2724	4822 122 33216 270pF 5% 50V
2725	4822 126 13196 CER2 SMD 25V 100N PM10 R
2726	4822 126 13196 CER2 SMD 25V 100N PM10 R
2728	5322 122 32966 39pF 5% 50V
2729	5322 122 32448 10pF 5% 50V
2730	4822 121 42004 10nF 10% 400V
2731	4822 126 14122 8.8nF 10% 50V
2732	4822 124 80606 1uF 20% 160V
2733	4822 122 33177 10nF 20% 50V
2734	4822 122 33216 270pF 5% 50V
2735	4822 126 13196 CER2 SMD 25V 100N PM10 R
2736	4822 126 13196 CER2 SMD 25V 100N PM10 R
2737	4822 053 10681 68000 5% 1W
2739	5322 122 32966 39pF 5% 50V
2740	5322 122 32448 10pF 5% 50V
2741	4822 124 42171 22uF 25V
2742	4822 121 42004 10nF 10% 400V
2743	4822 126 14122 8.8nF 10% 50V
2744	4822 124 80606 1uF 20% 160V
2745	4822 124 41751 47uF 20% 50V
2746	4822 124 40433 47uF 20% 25V
2747	4822 121 43693 10nF 100V
2748	4822 124 80131 100uF 20% 25V
2749	4822 126 13196 CER2 SMD 25V 100N PM10 R
2751	4822 124 80131 100uF 20% 25V
2752	5322 122 32654 22nF 10% 63V
2753	5322 122 32654 22nF 10% 63V
2754	4822 126 10326 180pF 5% 63V
2755	4822 124 80131 100uF 20% 25V
2756	4822 124 40433 47uF 20% 25V
2757	5322 124 40641 1uF 20% 100V
2760	5322 122 32658 22pF 5% 50V
2761	5322 122 32658 22pF 5% 50V
2762	5322 122 32658 22pF 5% 50V
2763	5322 122 32658 22pF 5% 50V
2764	4822 122 33177 10nF 20% 50V
2765	4822 126 10326 180pF 5% 63V
2766	5322 122 32448 10pF 5% 50V
2767	4822 122 32646 1uF 20% 50V
2768	4822 126 13196 CER2 SMD 25V 100N PM10 R
2769	4822 126 13196 CER2 SMD 25V 100N PM10 R
2770	4822 126 13196 CER2 SMD 25V 100N PM10 R
2771	4822 121 43693 10nF 100V
2772	4822 122 32966 39pF 5% 50V
2773	4822 126 12267 470pF 10%R(HR)

2774	4822 126 14102 2KV
2776	4822 126 13196 CER2 SMD 25V 100N PM10 R
2777	4822 252 60127 DSP-201M-C04F
2778	4822 122 33177 10nF 20% 50V
2779	4822 252 60127 DSP-201M-C04F
2780	4822 252 60127 DSP-201M-C04F
2781	4822 122 33177 10nF 20% 50V
2782	4822 124 40201 1000uF 20% 16V
2783	4822 124 40201 1000uF 20% 16V
2784	4822 126 13196 CER2 SMD 25V 100N PM10 R
2785	4822 126 13196 CER2 SMD 25V 100N PM10 R
2786	4822 126 13196 CER2 SMD 25V 100N PM10 R
2787	4822 126 13196 CER2 SMD 25V 100N PM10 R
2788	4822 126 13196 CER2 SMD 25V 100N PM10 R
2789	4822 126 13196 CER2 SMD 25V 100N PM10 R
2791	5322 124 40641 10uF 20% 100V
2792	5322 124 40641 10uF 20% 100V
2793	5322 124 40641 10uF 20% 100V
3701	4822 051 20759 75Q 5% 0.1W
3702	4822 051 20759 75Q 5% 0.1W
3703	4822 051 20759 75Q 5% 0.1W
3712	4822 051 20471 470Q 5% 0.1W
3713	4822 051 20471 470Q 5% 0.1W
3714	4822 051 20471 470Q 5% 0.1W
3715	4822 117 11503 220Q 1% 0.1W
3716	4822 117 11503 220Q 1% 0.1W
3717	4822 117 11503 220Q 1% 0.1W
3718	4822 117 11503 220Q 1% 0.1W
3719	4822 051 20331 330Q 5% 0.1W
3721	4822 051 20479 47Q 5% 0.1W
3722	4822 051 20479 47Q 5% 0.1W
3723	4822 051 20479 47Q 5% 0.1W
3724	4822 117 11503 220Q 1% 0.1W
3725	4822 051 20101 100Q 5% 0.1W
3726	4822 051 20101 100Q 5% 0.1W
3727	4822 051 20332 3K3 5% 0.1W
3728	4822 050 21009 10Q 1% 0.6W
3729	4822 051 20332 3K3 5% 0.1W
3731	4822 050 21009 10Q 1% 0.6W
3732	4822 051 20332 3K3 5% 0.1W
3733	4822 051 20109 10Q 5% 0.1W
3734	4822 051 20113 11K 5% 0.1W
3735	4822 050 22201 22Q 1% 0.6W
3736	4822 051 20479 47Q 5% 0.1W
3739	4822 051 20121 120Q 5% 0.1W
3740	4822 051 20229 22Q 5% 0.1W
3741	4822 051 20301 300Q 5% 0.1W
3743	4822 051 20392 3K9 5% 0.1W
3744	4822 051 20274 270K 5% 0.1W
3745	4822 051 20008 0Q JUMP. (SMD)
3746	4822 051 20479 47Q 5% 0.1W
3747	4822 051 20105 1M 5% 0.1W
3748	4822 050 21005 1M 1% 0.6W
3749	4822 051 20124 120K 5% 0.1W
3750	4822 050 22203 22K 1% 0.6W
3751	4822 117 10834 47K 1% 0.1W
3752	4822 116 52195 47Q 5% 0.5W
3753	4822 117 10833 10K 1% 0.1W
3754	4822 051 20479 47Q 5% 0.1W
3757	4822 051 20121 120Q 5% 0.1W
3758	4822 051 20301 300Q 5% 0.1W
3760	4822 051 20229 22Q 5% 0.1W
3761	4822 051 20382 3K9 5% 0.1W
3762	4822 051 20274 270K 5% 0.1W
3763	4822 051 20008 0Q JUMP. (SMD)
3764	4822 051 20479 47Q 5% 0.1W
3765	4822 051 20105 1M 5% 0.1W
3766	4822 050 21005 1M 1% 0.6W
3767	4822 051 20124 120K 5% 0.1W
3768	4822 050 22203 22K 1% 0.6W
3769	4822 116 52195 47Q 5% 0.5W
3770	4822 117 10834 47K 1% 0.1W
3771	4822 117 10833 10K 1% 0.1W
3772	4822 051 20479 47Q 5% 0.1W
3773	4822 051 20121 120Q 5% 0.1W
3776	4822 051 20301 300Q 5% 0.1W
3778	4822 051 20392 3K9 5% 0.1W
3779	4822 051 20274 270K 5% 0.1W
3780	4822 051 20105 1M 5% 0.1W
3781	4822 051 20008 0Q JUMP. (SMD)
3784	4822 050 21005 1M 1% 0.6W
3785	4822 051 20124 120K 5% 0.1W
3786	4822 050 22203 22K 1% 0.6W
3787	4822 116 52195 47Q 5% 0.5W
3788	4822 117 10833 10K 1% 0.1W
3789	4822 117 10834 47K 1% 0.1W
3790	4822 051 20229 22Q 5% 0.1W
3791	4822 050 13302 3K3 1% 0.4W
3792	4822 117 11139 1K5 1% 0.1W
3793	4822 051 20105 1M 5% 0.1W
3794	4822 051 20561 560Q 5% 0.1W
3795	4822 051 20182 1K8 5% 0.1W
3796	4822 051 20562 5K6 5% 0.1W
3797	4822 051 20332 3K3 5% 0.1W
3798	4822 051 20102 1K 5% 0.1W
3799	4822 051 20101 100Q 5% 0.1W
3800	4822 051 20479 47Q 5% 0.1W
3801	4822 051 20101 100Q 5% 0.1W
3802	4822 051 20101 100Q 5% 0.1W
3803	4822 116 82778 407 5% 1/6W
3804	4822 051 20102 1K 5% 0.1W
3806	4822 051 20102 1K 5% 0.1W
3807	4822 051 20102 1K 5% 0.1W
3808	4822 051 20102 1K 5% 0.1W
3811	4822 050 21502 1K5 1% 0.6W
3812	4822 116 80548 15K 5% 0.5W
3814	4822 117 10353 150Q 1% 0.1W
3815	4822 051 20101 100Q 5% 0.1W
3816	4822 051 20271 270Q 5% 0.1W
3829	4822 051 20101 100Q 5% 0.1W
3831	4822 051 20101 100Q 5% 0.1W
3832	4822 051 20101 100Q 5% 0.1W
5702	4822 152 20596 IND FXD SP0305 A 4U7 PM10 B
5703	4822 157 53519 IND FXD SP0406 A 100U PM10 B
5704	4822 152 20596 IND FXD SP0305 A 4U7 PM10 B
5705	4822 152 20596 IND FXD SP0305 A 4U7 PM10 B
5706	3136 126 78040 COL 0.15uH 10%
5707	3136 126 78040 COL 0.15uH 10%
5708	3136 126 78040 COL 0.15uH 10%
5709	4822 157 53189 CHOKO COIL 5.0uH PM10
5710	4822 152 20596 IND FXD SP0305 A 4U7 PM10 B
5711	4822 152 20596 IND FXD SP0305 A 4U7 PM10 B
5712	4822 152 20596 IND FXD SP0305 A 4U7 PM10 B
5713	4822 152 20596 IND FXD SP0305 A 4U7 PM10 B
6701	4822 130 80677 BAV103
6702	4822 130 30842 BAV21
6703	4822 130 80677 BAV103
6704	4822 130 30842 BAV21
6705	4822 130 80677 BAV103
6706	4822 130 30842 BAV21
6708	4822 130 42489 BYD03G
6709	4822 130 31678 1N4003G
6711	4822 130 80446 BAS32L
6712	5322 130 34337 BAV99
6713	5322 130 34337 BAV99
6714	4822 130 80446 BAS32L
6715	5322 130 34337 BAV99
6721	4822 130 80446 BAS32L
6724	4822 130 80446 BAS32L
6725	4822 130 80446 BAS32L
6734	4822 130 80446 BAS32L
7701	4822 209 16099 TDA4885
7702	4822 209 16103 LXC4389P1
7705	4822 130 41594 PH2369
7706	4822 130 41594 PH2369
7707	4822 130 41594 PH2369
7711	4822 130 41053 BC639
7716	4822 130 41053 BC639
7717	4822 130 41053 BC639
7723	4822 130 41053 BC639
7724	4822 130 41053 BC639
7725	5322 130 42136 BC848C
1158	3136 126 59270 EARPHONE PCB ASSY
1032	4822 267 31526 CON BM PHONE H OIP F 3.5 ST B
1033	4822 267 31526 CON BM PHONE H OIP F 3.5 ST B
-II-	
2081	5322 122 32654 22nF 10% 63V
2082	5322 122 32654 22nF 10% 63V
2084	4822 124 22678 100uF 20% 16V
2085	4822 124 23441 10uF 20% 50V
2086	4822 124 22681 47uF 20% 16V
2087	4822 124 22681 47uF 20% 16V
3081	4822 051 20331 330Q 5% 0.1W
3082	4822 051 20331 330Q 5% 0.1W
3083	4822 050 21502 1K5 1% 0.6W
3084	4822 051 20122 1K2 5% 0.1W
3085	4822 051 20122 1K2 5% 0.1W
6084	4822 130 31253 BZX79-C2V4

1159 Terminal-Panel
ASS'Y

Various

1288	3136 126 59280 TERMINAL PCB ASSY
1001	4822 277 21585 SWI SLJ B
1009	4822 266 10782 887 BM M 6P M2-50 RED B
1010	4822 265 10458 15P F 0.85
1002	4822 265 11176 75 OHM (ZL-6500)
1004	4822 265 11176 75 OHM (ZL-6500)
1006	4822 265 11176 75 OHM (ZL-6500)
1012	4822 265 11176 75 OHM (ZL-6500)
1014	4822 265 11176 75 OHM (ZL-6500)
2001	4822 124 80106 47uF 20% 16V
2002	5322 122 32658 470pF 10% 50V
2003	4822 124 80106 47uF 20% 16V
2004	4822 124 80106 47uF 20% 16V
2006	4822 124 80106 47uF 20% 16V
2007	4822 124 80106 47uF 20% 16V
2011	4822 126 11103 10nF 5% 50V
2012	4822 124 80106 47uF 20% 16V
2013	4822 124 11814 1uF 20% 50V
2104	4822 126 13196 CER2 SMD 25V 100N PM10 R

Various

3001	4822 051 20759 75Q 5% 0.1W
3002	4822 051 20759 75Q 5% 0.1W
3003	4822 051 20759 75Q 5% 0.1W
3004	4822 051 20759 75Q 5%

Quick Reference for 17" and 19" Monitors

Major Difference Between 19A580BQ/74C And 17A580BQ/74C

MODEL ITEM 12 NC	19A580BQ/74C	17A580BQ/74C
1	3138 107 94230 (Front Cabinet Assy)	3138 107 94670 (Front Cabinet Assy)
	3138 104 39260(Front Cabinet)	3138 104 40530 (Front Cabinet)
	3138 104 39310(LENS)	3138 104 40590(LENS)
	3138 104 39320(Function Knob)	3138 104 40580(Function Knob)
	x	3138 104 40600(Speaker-Grille)
	3138 104 39350(Speaker-Panel - R)	x
	3138 104 39340(Speaker Panel -L)	x
2	3138 104 39300(Rotary Knob)	3138 104 40720(Rotary Knob)
8	3138 104 39380(Power Knob)	3138 104 40710(Power Knob)
10	3138 107 94440(Cable Cover Assy)	3138 107 94730(Cable Cover Assy)
	3138 104 39330(Cable Cover)	3138 104 40610(Cable Cover)
	3138 106 49960(P.E. BAG)	3138 106 32610(P.E. BAG)
25	3138 107 94240(Pedestal Assy)	3138 107 94680(Bottom Plate Assy)
	3138 104 39280(Bottom)	3138 104 40550(Bottom)
	3138 104 39290(Base - Pedestal)	3138 104 40560(Base - Pedestal)
26	3138 104 39270(Back Cover)	3138 107 94960(Back Cover Assy)
	x	3138 104 40541(Back Cover)
	x	3138 104 41711(USB Cover)
27	3138 104 40950(USB Cover)	x
125	3138 105 35110(D.F.U.)	3138 105 35190(D.F.U.)
450	3138 106 51130(Carton)	3138 106 51790(Carton)
451	3138 106 51100(Cushion-Top-L)	3138 106 51340(Cushion-Top-L)
452	3138 106 51110(Cushion-Top-R)	3138 106 51350(Cushion-Top-R)
453	3138 106 51120(Cushion-Bottom)	3138 106 51360(Cushion-Bottom)
454	3138 106 38440(P.E. BAG for SET)	3138 106 39690(P.E. BAG for SET)
1155	4822 131 11275 M46LLQ 683X01(S)	4822 131 11277 M41KSX 683X24 (T)
1156	3138 128 62000(Main PCB Assy)	3138 128 62450(Main PCB Assy)
1158	3138 128 59270(Earphone PCB Assy)	3138 128 63380(Earphone PCB Assy)
1166	3138 128 77960(Degaussing Coil Assy)	3138 128 77930(Degaussing PCB Assy)
8160	x	3138 128 72740(Rotation Coll)

Difference List Between 3138 128 59270 And 3138 128 63380

MODEL ITEM 12 NC	3138 128 59270(Earphone PCB Assy)	3138 128 63380(Earphone PCB Assy)
2081	5322 122 32654(22n/50v)	x
2082	5322 122 32654(22n/50v)	x

Quick Reference for 17" and 19" Monitors (Continued)

Difference List

Difference List Between 3138 128 62000 And 3138 128 62450

MODEL ITEM 12 NC	19A580BQ/74C Main PCB Assy (3138 128 62000)	17A580BQ/74C Main PCB Assy (3138 128 62450)
1263	3138 128 63080(Eeprom Assy)	3138 128 63320(Eeprom Assy)
2603	4822 124 22669(1u/50v)	4822 124 23539(10u/50v)
2674	4822 121 70411(220n/250v)	4822 121 10708(180n/250v)
2681	4822 121 70241(120n/250v)	4822 121 70598(82n/400v)
3175	4822 050 24703(47 k)	4822 050 23904(39k)
3214	4822 051 20102(1 k)	4822 117 10833(10k)
3239	4822 052 10478(4R7)	4822 152 20596(4u7)
3245	4822 050 22203(22 k)	4822 050 21003(10k)
3481	4822 050 26203(62 k)	4822 050 25603(56k)
3501	4822 052 11228(2R2)	4822 052 11108(1 R)
3510	4822 052 11228(2R2)	4822 052 11108(1 R)
3556	4822 117 10442(10 R)	4822 117 12834(22 R)
3562	4822 050 21203(12 k)	4822 050 28202(8K2)
3563	4822 117 11383(12 k)	4822 051 20273(27 K)
3564	4822 051 20102(1 k)	4822 051 20562(5K6)
3566	4822 117 11383(12 k)	4822 117 10834(47 K)
3665	4822 117 10833(10 k)	4822 117 11383(12 K)
5101	3138 118 74160 (Line Filter 14 mH Min)	x
5101	x	3138 178 70890 (Line Filter 15 mH Min)
5102	3138 118 74160 (Line Filter 14 mH Min)	x

Difference List

MODEL ITEM 12 NC	19A580BQ/74C	17A580BQ/00C
125	3138 105 35110 D.F.U.	3138 105 35260 D.F.U.
126	3138 105 35210 QUICK SET UP GUIDE	3138 105 35200 QUICK SET UP GUIDE
127	x	3138 105 35330 QUICK SET UP GUIDE
450	3138 106 51130 CARTON	3138 106 51800 CARTON
1151	3138 128 75240 MAINS CORD	3138 128 75250 MAINS CORD

CM5800 BRIEF

A. GENERAL

The CM5800 is a Digitally Controlled Autoscans Color Display Monitor with 19" Low Emission CRT which is specially designed for low cost and high performance. This monitor can operate at horizontal scan frequencies from 30 to 95 kHz and vertical scan frequencies from 47 to 160 Hz.

This monitor is equipped with an embedded microcontroller which can preset the required modes. The CM5800 provides many functions, such as digitally adjustable picture, DDC1/2B, power management, low emission, high immunity, etc.

This monitor complies with MPRII low emission standard and also fulfills TCO'91 automatic power saving requirements. To reduce power consumption to less than 15 watts in standby or suspend mode and less than 5 watts in off mode, the monitor also complies with the energy star computer program initiated by the EPA.

B. DESCRIPTION OF CM5800

This description mainly introduces the functions, including power supply / power saving management, horizontal / vertical deflection, video amplifier, microcontroller, etc.

1. POWER SUPPLY / POWER SAVING MANAGEMENT

POWER SUPPLY:

This monitor is designed with an off-line flyback switch mode power supply which can operate with input from 90 VAC to 270 VAC. The power supply uses an IC (L4990) for current mode pwm controller and drives the mosfet switch directly. The control scheme transforms a switching converter from a voltage source into a multi-output voltage. The control concept exhibits many desirable properties such as inherent over-load protection, stable and fast system response.

The maximum power consumption is up to 130 watts. A power limiting circuit is added for safety reasons.

Secondary feedback via an optocoupler is used to obtain a stable output voltage. The secondary feedback supplies all necessary voltages for deflection and video. Voltage stabilizer IC is used to supply the small signals and microcontroller/EPROM.

POWER SAVING MANAGEMENT:

This monitor can reduce power consumption while no sync pulses are detected by microcontroller and automatically recover to normal power when sync signals are detected by microcontroller.

During power saving mode, the second power supply still delivers 5V to μ C (CPU). The consumed power is less than 15 watts during standby / suspend modes, and less than 5 watts during off mode.

2. HORIZONTAL / VERTICAL DEFLECTION

HORIZONTAL DEFLECTION:

SYNC PROCESSING PART:

The heart of horizontal/vertical deflection controller is TDA4858 which can offer complete and efficient small signal sync processing for autosync monitors. This device is fully dc controllable and can be used in applications with a microcontroller as well as stand-alone with potentiometer control.

CM5800 BRIEF

This controller provides sync processing, which can accept separate, composite (H+V) and sync-on-video input signals. A very short setting time after mode change for protection of external power components has been taken.

The TDA4858 provides extensive functions like a flexible smps block and a geometry control with facilities leading to excellent picture quality. This device also can directly drive the vertical deflection output stage, the line driver stage, the E/W output stage and the EHT stage. All controls are dc and tracked with the incoming frequencies.

DEFLECTION PART:

The horizontal deflection is built around the buck converter which makes it possible to combine H-deflection and EHT generator and allows size and e/w correction without influencing EHT.

The flyback pulse from the buck converter is used by the line output.

Transformer (LOT) generates the required 26.0kV anode voltage.

The adjustable focus (G3) and screen (G2) voltages are internally derived from the anode voltage. Other secondary windings are used to generate the voltages for G1 and horizontal raster DC shift. For 19 inch monitor also provides dynamic focus on G4 to get a good focus performance. (G4 also adjustable).

To guarantee constant EHT over the whole frequency range, the B+ is made tracked with H-frequency by means of a step down converter.

The horizontal size and east/west correction are obtained by varying the voltage of buck converter of the lower deflection circuit.

Five-capacitors switch and dc controlled linearity coil are designed for optimal screen linearity.

For safety reasons, x-ray protection circuit is included, and the control information sensing by TDA4858 will shut down the h-deflection (and thereby EHT generator) if the anode voltage exceeds a certain value.

This circuit is also used for beam current overload protection. Shut down the deflection in case the total beam current exceeds a certain limit to protect both CRT and LOT.

VERTICAL DEFLECTION:

The majority of vertical deflection functions is integrated by two ICs; TDA4858 and TDA8172.

The TDA4858 takes care of sync polarity correction, automatic catching and holding of the vertical oscillator, generation of sawtooth drive current for vertical output and vertical s-correction, and generation of a correct V-blanking pulse for video blanking during vertical retrace lines.

The TDA8172 which is a dc-coupled vertical deflection booster with differential input signals is suitable for color monitor. The output stage has thermal and soar protection, and high linear sawtooth signal amplification to obtain the required vertical deflection current.

To obtain a fast vertical retrace for non-VGA mode an external flyback supply is used.

3. VIDEO AMPLIFIER

The heart of the video circuit is TDA4885. This controller can drive the hybrid post-amp. CR6927 by buffer stage. The video DC level and gain at the cathode will be controlled by the software.

The red, green and blue video signals are amplified and inverted by the preamplifier to output stage and AC coupled to the CRT cathodes.

Three cut-off adjustments are provided to set the video black level at cathode for all three guns. Also three individual gain adjustments are provided to adjust the white point at maximum swing. Both cut-off and gain controls are digital type controlled by microprocessor. For limiting the beam current and preventing local doming, the beam current limit will automatically reduce the video swing in case the maximum beam current is exceeded (ABL adjustment: R3647).

Brightness control, which is controlled by TDA4885, reduces power consumption in video amplifier. To suppress the vertical retrace lines during vertical retrace, a vertical blanking pulse is added to grid 1.

A spot-killer circuit is also added to prevent CRT spot burn-in when the set is switched off.

DDC 1/2B:

Via SDA, data about the monitor, including the serial number, production codes, CRT type and applicable timings are stored in the EEPROM (24IC21). To avoid picture interference, the reading and writing processes are executed during vertical blanking which is informed by the vertical sync.

4. MICROCONTROLLER

GENERAL DESCRIPTION:

The Philips P87C380 microprocessor is used to control the monitor. The preset data are stored in EEPROM ST24W08.

HARDWARE DEFINITION:

A. KEYBOARD

There are 3 key pads and one rotary encoder at the front of monitor for the OSD control.

- OSD function key:

Push it to confirm entrance or exit from the OSD window

- Encoder:

To select or adjust the parameters which are chosen from OSD.

- Brightness key:

Push it, the OSD shows the window, then adjust with the encoder.

- Contrast key:

Push it, the OSD shows the window, then adjust with the encoder.

B. OSD WILL DISAPPEAR AND SAVE AUTOMATICALLY AFTER NON-OPERATION

C. SOFTWARE WILL CONTROL THE DPMS ACCORDING TO THE SYNC STATUS.

D. VIDEO PRESET MODES

Preset video resolution and sync. Polarities

Resolution modes	H frequency	V frequency	H	V
720 x 400	31.469K	70.087Hz (VGA)	-	+
640 x 480	31.469K	59.940Hz (VESA/60)	-	-
640 x 480	37.500K	75.000Hz (VESA/75)	-	-
640 x 480	43.269K	85.008Hz (VESA/85)	-	-
800 x 600	37.879K	60.317Hz (VESA/60)	+	+
800 x 600	46.875K	75.000Hz (VESA/75)	+	+
800 x 600	53.674K	85.061Hz (VESA/85)	+	+
1024 x 768	48.363K	60.004Hz (VESA/60)	-	-
1024 x 768	60.023K	75.029Hz (VESA/75)	+	+
1024 x 768	68.677K	84.997Hz (VESA/85)	+	+
1280 x 1024	63.981K	60.020Hz (VESA/60)	+	+
1280 x 1024	80.000K	75.000Hz (VESA/75)	+	+
1280 x 1024	91.146K	85.024Hz (VESA/85)	+	+
1600 x 1200	75.000K	60.000Hz (VESA/60)	+	+
1600 x 1200	93.750K	75.000Hz (VESA/75)	+	+

TELEVISION/MONITOR SAFETY GUIDELINES FOR THE PROFESSIONAL SERVICE TECHNICIAN

Safety Checks

After the original service problem has been corrected, a complete safety check should be made. Be sure to check over the entire set, not just the area where you have worked. Some previous service may have left an unsafe condition, which could be unknowingly passed on to your customer. Be sure to check all of the following:

Fire and Shock Hazard

1. Be sure all components are positioned in such a way as to avoid the possibility of adjacent component shorts. This is especially important on those chassis which are transported to and from the service shop.
2. Never release a repaired unit unless all protective devices such as insulators, barriers, covers, strain reliefs, and other hardware have been installed in accordance with the original design.
3. Soldering and wiring must be inspected to locate possible cold solder joints, solder splashes, sharp solder points, frayed leads, pinched leads, or damaged insulation (including the ac cord). Be certain to remove loose solder balls and all other loose foreign particles.
4. Check across-the-line components and other components for physical evidence of damage or deterioration and replace if necessary. Follow original layout, lead length, and dress.
5. No lead or component should touch a receiving tube or a resistor rated at 1 watt or more. Lead tension around protruding metal surfaces or edges must be avoided.
6. Critical components having special safety characteristics are identified with an s by the Ref. No. in the parts list and enclosed within a broken line* (where several critical components are grouped in one area) along with the safety symbols on the schematic diagrams and/or exploded views.
7. When servicing any unit, always use a separate isolation transformer for the chassis. Failure to use a separate isolation transformer may expose you to possible shock hazard, and may cause damage to measuring instruments.
8. Many electronic products use a polarized ac line cord (one wide pin on the plug). Defeating this safety feature may create a potential hazard to the service and the user. Extension cords which do not incorporate the polarizing feature should never be used.
9. After reassembly of the unit, always perform an ac leakage test or resistance test from the line cord to all exposed metal parts of the cabinet. Also, check all metal control shafts (with knobs removed), antenna terminals, handles, screws, etc. to be sure the unit may be safely operated without danger of electrical shock.

* Broken line - - - - -

Implosion

1. All picture tubes used in current model receivers are equipped with an integral implosion system. Care should always be used, and safety glasses worn, whenever handling any picture tube. Avoid scratching or otherwise damaging the picture tube during installation.
2. Use only replacement tubes specified by the manufacturer.


X-radiation

1. Be sure procedures and instructions to all your service personnel cover the subject of X-radiation. Potential sources of X-rays in TV receivers are the picture tube and the high voltage circuits. The basic precaution which must be exercised is to keep the high voltage at the factory recommended level.
2. To avoid possible exposure to X-radiation and electrical shock, only the manufacturer's specified anode connectors must be used.
3. It is essential that the service technician has an accurate HV meter available at all times. The calibration of this meter should be checked periodically against a reference standard.
4. When the HV circuitry is operating properly there is no possibility of an X-radiation problem. High voltage should always be kept at the manufacturer's rated value - no higher - for optimum performance. Every time a color set is serviced, the brightness should be run up and down while monitoring the HV with a meter to be certain that the HV is regulated correctly and does not exceed the specified value. We suggest that you and your technicians review test procedures so that HV and HV regulation are always checked as a standard servicing procedure, and the reason for this prudent routine is clearly understood by everyone. It is important to use an accurate and reliable HV meter. It is recommended that the HV reading be recorded on each customer's invoice, which will demonstrate a proper concern for the customer's safety.
5. When troubleshooting and making test measurements in a receiver with a problem of excessive high voltage, reduce the line voltage by means of a Variac to bring the HV into acceptable limits while troubleshooting. Do not operate the chassis longer than necessary to locate the cause of the excessive HV.

6. New picture tubes are specifically designed to withstand higher operating voltages without creating undesirable X-radiation. It is strongly recommended that any shop test fixture which is to be used with the new higher voltage chassis be equipped with one of the new type tubes designed for this service. Addition of a permanently connected HV meter to the shop test fixture is advisable. The CRT types used in these new sets should never be replaced with any other types, as this may result in excessive X-radiation. It is essential to use the specified picture tube to avoid a possible X-radiation problem.
8. Most TV receivers contain some type of emergency "Hold Down" circuit to prevent HV from rising to excessive levels in the presence of a failure mode. These various circuits should be understood by all technicians servicing them, especially since many hold down circuits are inoperative as long as the receiver performs normally.

Leakage Current Cold Check

1. Unplug the ac line cord and connect a jumper between the two prongs of the plug.
2. Turn on the power switch.
3. Measure the resistance value between the jumpered ac plug and all exposed cabinet parts of the receiver, such as screw heads, antennas, and control shafts. When the exposed metallic part has a return path to the chassis, the reading should be between 1 megohm and 5.2 megohms. When the exposed metal does not have a return path to the chassis, the reading must be infinity. Remove the jumper from the ac line cord.



Leakage Current Hot Check

1. Do not use an isolation transformer for this test. Plug the completely reassembled receiver directly into the ac outlet.
2. Connect a 1.5k, 10W resistor paralleled by a 0.15µF capacitor between each exposed metallic cabinet part and a good earth ground such as a water pipe, as shown above.
3. Use an ac voltmeter with at least 5000 ohms/volt sensitivity to measure the potential across the resistor.
4. The potential at any point should not exceed 0.75 volts. A leakage current tester may be used to make this test; leakage current must not exceed 0.5milliamps. If a measurement is outside of the specified limits, there is a possibility of shock hazard. The receiver should be repaired and rechecked before returning it to the customer.
5. Repeat the above procedure with the ac plug reversed. (Note: An ac adapter is necessary when a polarized plug is used. Do not defeat the polarizing feature of the plug.)

Picture Tube Replacement

The primary source of X-radiation in this television receiver is the picture tube. The picture tube utilized in this chassis is specially constructed to limit X-radiation emissions. For continued X-radiation protection, the replacement tube must be the same type as the original, including suffix letter, or a Philips approved type.

Parts Replacement

Many electrical and mechanical parts in Philips television sets have special safety related characteristics. These characteristics are often not evident from visual inspection nor can the protection afforded by them necessarily be obtained by using replacement components rated for higher voltage, wattage, etc. The use of a substitute part which does not have the same safety characteristics as the Philips recommended replacement part shown in this service manual may create shock, fire, or other hazards.

Service Service Service

Service Information

Service information 4822 727 21038 is herewith cancelled.


This [DDC Module (DDC cable)= 4822 320 12004(=4822 724 27550)] and [DDC V2(DDCV2N.EXE) software(3.5" disk)=4822 711 00024(= 4822 724 27560)] are used for "BU Monitor - Chungli product range" which incorporates a DDC1/DDC2B function that allows bi-directional communication between the monitor and PC system for optimal video configuration. [July 01 1997, Revision 2.0], which upgrades the software and service information(4822 727 21027 & 4822 727 21038), is fully compatible with previous one.

Additional information :

Additional information about DDC (Display Data Channel) may be obtained from Video Electronics Standards Association (VESA). Extended Display Identification (EDID) information may be also be obtained from VESA.

Pin assignment


The 15-pin D-sub connector (male) of the signal cable (3 rows) for DDC feature :



Pin No.	Assignment	Pin No.	Assignment
1	Red video input	9	No pin
2	Green video input	10	Logic ground
3	Blue video input	11	Identical output connected to pin 10
4	Identical output connected to pin 10	12	Serial data line (SDA)
5	Ground	13	H.sync
6	Red video ground	14	V. sync (VCLK for DDC)
7	Green video ground	15	Data clock (SCL)
8	Blue video ground		

Connection

(Rear of the monitor)



DDC data re-programming

1. General
In case the DDC data memory IC, replaced due to a defect the data contents of this IC have to be re-programmed via a PC.
In case of replacement of the video board it is advised to re-soldered DDC IC from the old board onto the new board, in this case the IC does not need to be re-programmed.

2. DDCV2N.EXE can be used for :
EDID Structure Version/Revision

Version	: 1	
Revision	: 0	(text file)
and		
Version	: 1	
Revision	: 1	(.hex file)

WARNING: Before removing the CRT anode cap, turn the unit **OFF** and short the HIGH VOLTAGE to the CRT DAG ground.
SERVICE NOTE: The CRT DAG is not at chassis ground.

Published by BU Monitor Printed in The Netherlands *Copyright reserved Subject to modification Oct. 31 1997 4822 727 21995



PHILIPS

DDC Reprogramming Instruction (for PHILIPS Branded models)

System Requirements

DDC Module (DDC cable), P/N = 4822 320 12004
 An Intel 386 (or above) PC or compatible
 DOS 6.0 or above
 DDCV2N.EXE software

Procedure

Connect DDC Cable as shown in cover page.
 Insert diskette in Drive a: Select Run "**DDCV2N.EXE**" under DOS or Win.
 Press "**Enter**" at the introduction screen

Menu Configuration:

File	R/W	Setup	Quit
Load EDID	Write EDID to EEPROM	Options	
Load txt file (V1.0)	Read From EEPROM	Barcode format	
Save EDID	Edit EDID Code		
Save txt File	Auto Scan		
Convert EDID Code			
Os shell			
Exit			

General :

1. How to change drive

Use arrow keys to highlight "**Options**" under the Setup menu, Press "**Enter**".
 Press "**F2**", then Press "**ESC**", fill in "**A**" or "**C**".
 [(If your .HEX files for different Model numbers in drive "A", then fill in "A").,
 (If your .HEX files for different Model numbers in drive "C", then fill in "C").
 Normally, to read DDC data from EEPROM of Monitor is enough.]

Press "**Enter**", then Press "**ESC**"

2. How to select .HEX files for different Model numbers example:

Use arrow keys to highlight "**Load EDID**" under the File menu, Press "**Enter**"
 Bring up **BRANDED** Press "**Enter**"

Bring up
 ..\21B772BE\
 CM58\ ← select, Press "**Enter**"

Bring up
 ..\19A74C.HEX ← at this highlight area, Press "**Enter**", then go back to last screen
 19A00C.HEX ← select for 19A580BQ/74C
 19A00C.HEX ← select for 19A580BQ/00C

How to write DDC hex files to Monitor

Use arrow keys to highlight "**Options**" under the Setup menu, Press "**Enter**"

Tab down to ID Serial Number, Use down arrow key to place the asterisk (*) beside "store in DEC with LSB first". Press "**control/enter**" to save.
 (Ensure the top asterisk (*) is beside in store in HEX with LSB first.)

Use arrow keys to highlight "**Load EDID**" under the file menu, Press "**Enter**".

Use arrow keys to highlight "**BRANDED**", Press "**Enter**".

Use arrow keys to highlight "**the model list under subdirectly**", Press "**Enter**".

Use arrow keys to highlight "**Write EDID to EEPROM**" under the R/W menu, Press "**Enter**".

Use arrow keys to highlight "**Read from EEPROM**" under the R/W menu, Press "**Enter**".

Use arrow keys to highlight "**Edit EDID Code**" under the R/W menu, Press "**Enter**".

Verify the ID Serial number on the screen matches the serial number of the unit.

Verify EDID Structure Version is "Version :1, Revision :1

Press "**ESC**"

Use arrow keys to highlight "**Quit**", Press "**Enter**".

Menu Configuration:

File	R/W	Setup	Quit
Load EDID	Write EDID to EEPROM	Options	
Load txt file (V1.0)	Read From EEPROM	Barcode format	
Save EDID	Edit EDID Code		
Save txt File	Auto Scan		
Convert EDID Code			
Os shell			
Exit			

Remark: ID product code and ID Serial Number setting are for "PHILIPS" & "STENCIL" DDC TEXT

INSTRUCTIONS

How to change the Year, Week & Serial number of Monitor (for BRANDED models)

Use arrow keys to highlight "Barcode format", under the Setup menu, Press "Enter".

Bring up : Barcode example : 9741222266
Barcode format : YYWWSSSSSS
Fill in 9741222266, press "Enter"
Fill in yywwssssss, press "Enter"

continue : Barcode example : 9741222266
Barcode format : YYWWSSSSSS

Manufacture Year : 1997
Manufacture Week : 41
Serial no. : 222266

EDID [16] Week : 29
EDID [17] Year : 07 [Year-1990]
EDID [12..15] S/N. : 0003643a

data correct ? (Y/N) Y

Fill in "Y", don't press "Enter"

There is a description at the lower of the screen for Barcode format as below.

Barcode format : Y,W,S,X,- (year,week,s/no,ignore,fixed)

Y stands for "year".
W stands for "week".
S stands for "s/no (serial number)".
X stands for "ignore". Allow user to fill in any 'character' or 'numeric'.
- stands for "fixed". User have to fill in Special 'character' or 'numeric' for "AutoScan" if user fill in '-' at "Barcode format :".

Use arrow keys to highlight "Auto Scan" under the R/W menu, Press "Enter".

Bring up : Auto Scan ← year, week, serial number can be changed
◆◆◆◆◆
□ SerialNumber
◇ YearCode
△ WeekCode
★ don't care

Fill in "Barcode data (for instance: 9741222266)" beside Auto Scan, press "Enter"

9745000240
9640001000

Press "ESC" "ESC", return to R/W menu.
PCS 90 034

How to change the serial number of Monitor (for PCEC models)

Use arrow keys to highlight "Barcode format", under the Setup menu, Press "Enter".

Bring up : Barcode example : 5800C12345678
Barcode format : XXXXXSSSSSSSS
Fill in 5800C12345678, press "Enter"
Fill in xxxxxxxsssss, press "Enter"

continued : Barcode example : 5800C12345678
Barcode format : XXXXXSSSSSSSS

Manufacture Year : 1997
Manufacture Week : 40
Serial no. : 12345678
Serial no. ASCII : 5800C12345678

data correct ? (Y/N) Y

(can be changed), press "Enter"
(can be changed), press "Enter"

Fill in 5800C12345678, press "Enter"

Fill in "Y", don't press "Enter"

There is a description at the lower of the screen for Barcode format as below.

Barcode format : Y,W,S,X,- (year,week,s/no,ignore,fixed)

Y stands for "year".
W stands for "week".
S stands for "s/no (serial number)".
X stands for "ignore". Allow user to fill in any 'character' or 'numeric'.
- stands for "fixed". User have to fill in Special 'character' or 'numeric' for "AutoScan" if user fill in '-' at "Barcode format :".

Use arrow keys to highlight "Auto Scan" under the R/W menu, Press "Enter".

Bring up : Auto Scan ← year, week, serial number can be changed
□ SerialNumber
◇ YearCode
△ WeekCode
★ don't care

Fill in "Barcode data (for instance: 5800C12345678)" beside Auto Scan, press "Enter"

5800J28256153
58008H75602720

Press "ESC" "ESC", return to R/W menu.

For the original DDC TEXT file:

Use arrow keys to highlight "Load txt file (V1.0)" under the File menu, Press "Enter"

1. Data text file editing options
The data text file can be edited by the DOS-editor.

2. Re-programming instructions
 - Turn on PC and monitor
 - Connect the module to the PC and monitor, see connection figure on front page.
 - Insert the floppy disk into drive A: and follow the following routine:
 - Type "DDC" and then press "ENTER". On the screen it will show:"Adaptor check...", then the screen will display "main menu".
 - Use the arrow keys to highlighting items 1, 2, 3, 4, 0 :

Step 1 - Select item "1", which appear as a highlight, and press "ENTER" to convert a text data into EDID data.
- Enter the text file name with directory path eg. "a:\CM0200\BND14PHL.TXT" and press "ENTER".
The available text file on the floppy will now be converted into a binary file that can be downloaded into the memory IC.
- Press "ENTER" to continue, the program will return to main menu.

Step 2 - Select item "2", under the main menu , and press "ENTER" to write a complete EDID data file to EEPROM. Now, the data will be loaded into the memory IC.
- Press "ENTER" to continue, the program will return to main menu.

Step 3 - Select item "3", under the main menu, and press "ENTER" to verify that EDID downloading is successful. This function also can be used to view current DDC data in monitor.
- Press "ENTER" and follow the indication on the screen to return main menu.

Step 4 - Select item "4", under the main menu, and press "ENTER" to enter DOS prompt and DOS Editor of your system. By DOS Editor, the function allow you to modify or update DDC data eg. manufacturing week, serial number etc according to the rear cover type label of the set.
The production serial number of type label consist of:
TY - origin of production centre
00 - technical service change code
95 - production year
12 - production week
123456 - 6 digits (max) serial number

Once the modification of DDC text file is completed under DOS Editor, Quit to DOS prompt and return to main menu by typing "EXIT" and press "ENTER".
After text file is modified according above description, you can repeat the process of step 1 to step 3 to re-program DDC data again.

Step 5 - Select item "0", under the main menu, and press "ENTER" to quit DDC program and return to DOS prompt.

3. Remark 1 :

During the re-programming, it is recommended to follow step 1, step 2, and step 3.
Due to different format requirements by customer, If read DDC data from monitor by step 3 , product ID and serial number will show 3 formats, <decimal>, <hexa-decimal>, and <ASCII>, the correct format can be obtained by running step 1 again (the correct format can be detected and identified automatically by step 1 from original text file).

Setting Up your Philips monitor

Installation de votre moniteur Philips.


Configuración de su monitor Philips.

IBM-compatible computer hookup continued from step 1 on other side.

Connecter l'ordinateur compatible IBM, suite de la première étape de l'autre côté.

Conexión del ordenador compatible con IBM (continuación del paso 1 del otro lado de la página).


- 2** Turn off the computer. Then connect the monitor cable.



Eteindre l'ordinateur, puis connecter le câble du moniteur.

Apague el ordenador. Luego conecte el cable del monitor.


- 3** Connect the power cable. Make sure the power plug and the wall socket are easily accessible.



Connecter le câble de puissance. S'assurer que la fiche secteur et la prise murale soient facilement accessibles.

Conecte el cable de energía. Verifique que se pueda acceder fácilmente al tomacorriente y al enchufe de pared.

- 4** Turn on the monitor. Then turn on the computer.



Allumer le moniteur, puis l'ordinateur.

Encienda el monitor. Luego encienda el ordenador.

If you have Windows '95...

follow these steps to complete setting up your monitor.

1. Start Windows '95 and install CD ROM supplied with this monitor.
2. Click on the "START" icon. Next, click on the "SETTINGS" icon. Then click on "CONTROL PANEL."
3. Double-click on "DISPLAY" icon. Next, click on "SETTINGS" tab. Then click on "ADVANCED PROPERTIES" dialog box.
4. Click on "MONITOR" tab.
- 5a. If you have an old computer, click on "CHANGE" dialog box. Next, "SELECT DEVICE" screen appears. Now click on "HAVE DISK" dialog box, and select CD-ROM drive Or
- 5b. If you have a new computer, "SELECT DEVICE" screen automatically appears. Click on "HAVE DISK" dialog box and select CD-ROM drive.
6. Select "OK" in the "INSTALL FROM DISK" dialog box. If model name of the Philips monitor is correct, click "OK" tab in the "SELECT DEVICE" dialog box.
7. Click "CLOSE" tab in the "ADVANCED PROPERTIES" dialog box. If your Windows '95 version is different or you need more detailed installation information, please refer to the Windows '95 user's manual. For additional information on the monitor, please refer to the owner's manual.

Si vous avez Windows '95...

suivez les étapes suivantes pour terminer l'installation de votre moniteur.

1. Démarrer Windows 95 et installer le CD-ROM fourni avec votre moniteur.
2. Cliquer sur l'icône "DÉMARRER", ensuite, cliquer sur l'icône "PARAMETRES", puis cliquer sur l'icône "Panneau de configuration".
3. Cliquer deux fois sur l'icône "AFFICHER", ensuite cliquer sur l'onglet "PARAMETRES", puis cliquer sur la boîte de dialogue "PROPRIÉTÉS AVANCÉES".
4. Cliquer sur l'onglet "MONITEUR".
- 5a. Si vous avez un ancien ordinateur, cliquer sur la boîte de dialogue "CHANGER", ensuite l'écran "SELECTIONNER UNITÉ" apparaît. Maintenant cliquer sur la boîte de dialogue "DISQUETTE FOURNIE", et sélectionner le lecteur CD-ROM. ou
- 5b. Si vous avez un ordinateur récent, l'écran "SELECTIONNER UNITÉ" apparaît automatiquement. Cliquer sur la boîte de dialogue "DISQUETTE FOURNIE" et sélectionner le lecteur CD-ROM.
6. Sélectionner "OK" dans la boîte de dialogue "INSTALLER À PARTIR DE LA DISQUETTE". Si le nom du modèle de moniteur Philips est correct, cliquer sur l'onglet "OK" dans la boîte de dialogue "SELECTIONNER UNITÉ".
7. Cliquer sur l'onglet "FERMER" dans la boîte de dialogue "PROPRIÉTÉS AVANCÉES". Si votre version Windows 95 est différente ou si vous voulez des informations plus détaillées sur l'installation, veuillez vous référer au manuel d'utilisateur de Windows 95. Pour des informations complémentaires sur le moniteur, veuillez vous référer au manuel d'utilisateur.

WHAT TO DO IF YOUR MONITOR ISN'T WORKING

Make sure...

- ...the Power cable is plugged in the wall and the rear of the monitor.
 - ...the Power button on top of the monitor should be in the ON position.
 - ...the monitor cable is properly connected to the back of the monitor and the computer.
 - ...to check to see if the monitor cable has bent pins.
 - ...the D-Sub/BNC switch on the rear of the monitor is in the correct position.
- See pages 2 and 17 of the owner's manual for details.
See page 20 of the owner's manual for troubleshooting tips.
For warranty questions, please see your owner's manual.

QUE FAIRE SI VOTRE MONITEUR NE MARCHE PAS

S'assurer...

- ...que le câble de puissance soit branché dans le mur et à l'arrière du moniteur.
 - ...que le bouton Marche/Arrêt au dessus de votre moniteur soit sur MARCHE.
 - ...que le câble du moniteur soit bien connecté à l'arrière du moniteur et de l'ordinateur.
 - ...de vérifier que le câble du moniteur n'ait pas de fiches tordues.
 - ...que l'interrupteur D-Sub/BNC à l'arrière du moniteur soit en position correcte.
- Voir page 24 et 39 de votre manuel d'utilisateur pour plus de détails.
Voir page 42 du manuel d'utilisateur pour des conseils de dépannage.
Si vous avez des questions concernant la garantie, veuillez consulter votre manuel d'utilisateur.

¿QUÉ HACER SI SU MONITOR NO FUNCIONA?

Verifique...

- ...si el cable de energía está enchufado a la fuente de energía y a la parte posterior del monitor.
- ...si el botón de alimentación en la parte superior del monitor está en la posición ON.
- ...si el cable del monitor está debidamente conectado a la parte posterior del monitor y del ordenador.
- ...que las clavijas del cable del monitor no estén dobladas.
- ...que el interruptor D-Sub/BNC en la parte posterior del monitor esté en la posición correcta. Si desea más detalles, consulte las páginas 46 y 61 del manual del propietario.

En la página 64 del manual del propietario encontrará consejos sobre la localización de fallas.

Para consultas sobre la garantía, consulte el manual del propietario.

Si tiene Windows '95...

siga estos pasos para finalizar la configuración de su monitor.

1. Inicie Windows '95 e instale el CD ROM que se suministra con su monitor.
2. Haga clic en el icono "INICIO". Luego haga clic en el icono "CONFIGURACIÓN". Luego haga clic en "PANEL DE CONTROL".
3. Haga doble clic en el icono "PANTALLA". A continuación haga clic en la etiqueta "CONFIGURACIÓN" y luego en el cuadro de diálogo "PROPIEDADES AVANZADAS".
4. Haga clic en la etiqueta "MONITOR".
- 5a. Si usted tiene un ordenador viejo, haga clic en el cuadro de diálogo "CAMBIAR". Luego aparece la pantalla "SELECCIÓN DE DISPOSITIVO". Ahora haga clic en el cuadro de diálogo "UTILIZAR DISCO" y seleccione la unidad CD-ROM. O
- 5b. Si tiene un ordenador nuevo, aparece automáticamente la pantalla "SELECCIONAR DISPOSITIVO". Haga clic en el cuadro de diálogo "UTILIZAR DISCO" y seleccione la unidad CD-ROM.
6. Seleccione "ACEPTAR" en el cuadro de diálogo "INSTALAR DESDE DISCO". Si el nombre del modelo del monitor Philips está correcto, haga clic en la etiqueta "ACEPTAR" del cuadro de diálogo "SELECCIÓN DE DISPOSITIVO".
7. Haga clic en la etiqueta "CERRAR" del cuadro de diálogo "PROPIEDADES AVANZADAS". Si su versión de Windows '95 es diferente o necesita información más detallada acerca de la instalación, consulte el manual del usuario de Windows '95. Si desea información adicional acerca del monitor, consulte el manual del propietario.

Setting Up your Philips monitor


Installation de votre moniteur Philips.

Configuración de su monitor Philips.

This foldout is designed to help you use your monitor as soon as possible. Refer to your owner's manual for detailed information. You may also contact us at our web site: <http://www.monitors.be.philips.com>

Ce dépliant est conçu pour vous aider à utiliser votre moniteur du plus vite possible. Consultez votre manuel d'utilisateur pour des informations détaillées. Vous pouvez aussi nous contacter sur notre site Web: <http://www.monitors.be.philips.com>


Esta hoja plegable está diseñada para ayudarle a usar su monitor tan pronto como sea posible. Consulte su manual si desea información detallada. También puede comunicarse con nosotros a través de nuestra página web: <http://www.monitors.be.philips.com>



Monitor
Moniteur
Monitor

1 Unpack all the parts. Déballer toutes les pièces. Desembale todas las piezas.


Monitor cable
Câble du moniteur
Cable del monitor





Macintosh adapter (optional)
Carte Macintosh (optionnelle)
Adaptador de Macintosh (opcional)



Power cable
(Appearance may vary.)
Câble de puissance (l'apparence varie)
Cable de energía (su aspecto puede variar)





Audio cable
Câble audio
Cable de audio



CD ROM or Floppy Disk
CD-ROM ou Floppy Disk
CD ROM or Floppy Disk




Microphone cable
Câble du microphone
Cable del micrófono



Owner's manual
Manuel d'utilisateur
Manual del propietario


2 Connect the special Mac adapter (May not be included.) to one end of the monitor cable.



Connecter la carte spéciale Mac (pas toujours incluse) à une extrémité du câble du moniteur.

Conecte el adaptador especial de Mac (puede no estar incluido) a un extremo del cable del monitor.


3 Turn off the computer. Then connect the monitor cable.



Eteindre l'ordinateur, puis connecter le câble du moniteur

Apague el ordenador. Luego conecte el cable del monitor.


4 Connect the power cable. Make sure the power plug and the wall socket are easily accessible.



Connecter le câble de puissance. S'assurer que la fiche secteur et la prise murale soient facilement accessibles.

Conecte el cable de energía. Verifique que se pueda acceder fácilmente al tomacorriente y al enchufe de pared.

5 Turn on the monitor. Then turn on the computer.



Allumer le moniteur, puis l'ordinateur.

Encienda el monitor. Luego encienda el ordenador.

CustoMax for your monitor

version 3.0

The information in this document is subject to change without notice and does not represent a commitment on the part of the developer.

The software may be used or copied only in accordance with the terms of the agreement.

In no event will the developer of this product be liable for direct, indirect, special, incidental or consequential damages arising out of the use or inability to use this product or documentation, even if advised of the possibility of such damages.

This document contains materials protected by copyright. All rights are reserved. No part of this manual may be reproduced or transmitted in any form, by any means or for any purpose without expressing written consent.

PHILIPS and the PHILIPS logo are registered trademarks of PHILIPS Electronics N.V.

MS-DOS and Windows are registered trademarks of Microsoft Corporation.

IBM PC/XT/AT/386/486 are registered trademarks of International Business Machines Corporation.

TABLE OF CONTENTS

1. The content of the package
2. Installation
3. CustoMax, how it works
4. CustoMax quick overview
 - 4.1. Sound & Vision controls
 - 4.2. Screen geometry controls
 - 4.3. Colour quality controls
 - 4.4. Image quality controls
 - 4.5. Hardware & Software settings
 - 4.6. User guidance

1. THE CONTENT OF THE PACKAGE

In the package you should find

The USB module

The USB cable

The CD-ROM with the CustoMax software & USB device driver on it

The Directions for use

2. INSTALLATION

System requirements

Hardware : a PC which supports the USB function and has a USB outlet.

Software: Windows system which supports USB (Win 95 2.1 or Win 98).

Installation of USB module

1. Turn off the monitor and unplug the power cord.
2. Remove the cover of "USBAY" at the back of the monitor.
3. Insert USB module into the slot.
4. Fix the USB module to the monitor by screwing.
5. Plug-in the power cord and turn on the monitor.

To establish the USB connection

6. Insert CD-Rom
7. The two ends of USB cable attached are different. Plug-in the square end into the "upstream" outlet of the USB module.
8. Plug-in the other end into the USB outlet of the PC.
9. Windows recognises two new pieces of hardware
 - Philips USB hub
 - USB Human Interface Device

This last item is presented through a wizard.

Follow the "next" steps on screen (choose the recommended options) until installation has been finished

Usages Tips: Check device manager tab in system manager properties.


Human Interface devices

- Philips CustoMax (USB monitor control)


Universal serial bus controller

- Philips USB Hub


if




select properties




select driver




select Update Driver




select next



select next



select next



select next

then follow Wizard

Installation of CustoMax

10. Double click on CD-Rom icon

11. Start the CustoMax installation program: CustoMax 3.exe

CustoMax

Start CustoMax using one of these four ways

1. Icon on the right-side of the taskbar
2. Tab in display properties
3. Start menu
4. ctrl-alt-c

There is no need to turn off the PC or monitor when establish USB connection.

Installation of CustoMax

1. Install the USB module and connect the USB cable between your monitor & PC.
 2. Put the CD-ROM in the CD-ROM drive.
 3. Click on the CD-ROM icon.
 4. Follow the installation instructions on the screen.
- Plug-in the desired peripherals into the "downstream" outlets of the USB module.

Usage tips

The shortcut to start-up CustoMax is ctrl + alt + c.
If installed on a network server: the settings will be stored locally.

3. CUSTOMAX 3.0, HOW IT WORKS

CustoMax 3.0 for monitors is a software program for adjusting the audio and video, screen geometry, colour quality, image quality and hardware and software settings through USB. The start-up settings of CustoMax, Window Background and Language can be changed.

Note. When CustoMax is started up for the first time, the default setting being activated will be the 'Hardware & Software Settings'. Within the 'Hardware & Software Settings' you first will have to select the type of monitor you currently have in your configuration.

Default Enables you to change the default selected menu
Usages tip: we recommend sound & vision as default menu.

Main procedures for using CustoMax:

1. To select a specific part of CustoMax, choose one of the four navigation buttons on the left side of the CustoMax window.
2. Select on of the buttons in the 'Operation' area.
3. Perform adjustments by using the buttons in the 'Adjustment' area of the CustoMax window.

Usage tips

To switch off, or on, the 'How to..' Help, select the '?' button, on the right side of the CustoMax window.
To perform adjustments, the contrast and brightness of the screen should be fairly normal and user controllable.

As soon as you finish the program, a DONE is automatically executed to store all settings. Also, before changing the main menu, a DONE is automatically executed. This minimizes the amount of times having to press DONE.

4. CUSTOMAX, QUICK OVERVIEW

4.1. SOUND & VISION CONTROL

SOUND & VISION CONTROL

To adjust audio and video levels. The options to adjust are: Mute, Volume, Balance, Bass, Treble, Brightness, and Contrast.

MUTE

To switch off/on the sound.

VOLUME

To change the sound level.

BALANCE

To change the sound balance.

BASS

To change the bass level.

TREBLE

With the 'Treble' function you can change the treble level.

BRIGHTNESS

To change the brightness level.

CONTRAST

To change the contrast level.

CONTRAST PATTERN 1

To help you adjust the contrast level.

CONTRAST PATTERN 2

To help you adjust the contrast level.

ADJUSTMENT BUTTONS

To make adjustments to the audio and video levels.

DONE

To save any changes and selections made before closing and returning to the display of the five main navigation and Help buttons.

UNDO

To undo any changes and selections made in this particular part of CustoMax.

Usage Tips

- ù The Mute, Volume, Balance, Bass, Treble, Brightness, and Contrast buttons appear after Sound & Vision Control has been selected.
- ù With the left mouse button a selected contrast pattern can be toggled to the foreground or background.
- ù The Adjustments Buttons only appear after an audio or video button has been selected.
- ù The Done and Undo buttons appears after one of the five main navigation buttons on the left side of the CustoMax window has been selected.
- ù The Undo function will only be executed after an additional confirmation has been made in the pop-up window.

4.3. COLOUR QUALITY CONTROL

COLOUR QUALITY CONTROL

To adjust the colour temperature.

DEGAUSS

To demagnetise the monitor's screen surface.

FACTORY COLOUR PRESET

To reset the current user-defined colour will back to default. User preset 1 is reset to 9300 K, user preset 2 is reset to 6500 K, and user preset 3 is reset to 5500 K.

FACTORY PRESET 1

To set the colour temperature to 9300 K

FACTORY PRESET 2

To set the colour temperature to 6500 K

FACTORY PRESET 3

To set the colour temperature to 5500 K

USER DEFINABLE PRESETS 1

To change the colour temperature to a user-defined preset.

USER DEFINABLE PRESETS 2

To change the colour temperature to a user-defined preset.

USER DEFINABLE PRESETS 3

To change the colour temperature to a user-defined preset.

RED BACKGROUND COLOUR

To help you adjust the colour balance setting.

GREEN BACKGROUND COLOUR

To help you adjust the colour balance setting.

BLUE BACKGROUND COLOUR

To help you adjust the colour balance setting.

COMBINED BACKGROUND COLOUR

To help you adjust the colour balance setting.

WHITE BACKGROUND COLOUR

To help you adjust the colour balance setting.

COLOUR TRIANGLE

To increase or decrease the proportion of each of the colours Red, Green or Blue.

DONE

To save any changes and selections made before closing and returning to the display of the five main navigation and Help buttons.

UNDO

To undo any changes and selections made in this particular part of CustoMax.

Usage Tips

- ù The Degauss function is available under Screen Geometry Control, Colour Quality Control and Image Quality Control.
- ù The number of available presets depends on the type of monitor you have selected in the Hardware & Software Settings part of CustoMax.
- ù The specific colour temperatures in the three Factory Presets cannot be changed.
- ù Adjustments to the colour temperature settings can only be made after first selecting one of the three user presets.
- ù To undo the reset to factory default, and to change back to the last defined user preset: Press Undo. The Factory Colour Preset function will immediately be executed, but can be changed back to the last defined user preset by selecting Undo.
- ù Move a Draggable Marker in the Colour Triangle, in the Adjustment area of the CustoMax window, to a new position on its axis. Alternatively, drag the central point of the triangle to a new position, or click directly on the new position in the triangle.

HARDWARE & SOFTWARE SETTINGS**HARDWARE & SOFTWARE SETTINGS**

To influence the behaviour of your monitor.

HARDWARE & SOFTWARE SETTINGS

To influence the behaviour of your monitor.

POWER SAVER

To reduce monitor power consumption

START-UP function

To activate or to select the default Navigation setting at start-up. The options are: 'Sound & Vision', 'Geometry', 'Colour Quality', 'Image Quality', or 'Hard- & Software'.

CUSTOMAX WINDOW BACKGROUND

To select a different CustoMax window background. The options are 'Water', 'Fire', 'Air', 'Earth', 'Glas', 'Leave', 'Flowers', 'Monitor housing', 'PCB', 'Doodle', 'Solid Background 1', 'Solid Background 2'.

LANGUAGE

To change to another language. The options are: 'UK English', 'US English', 'Deutsch', 'Français', 'Italiano' and 'Español'.

MONITOR TYPE

To select the present type of monitor. The options are: '107', '109', and '201B'.

HARDWARE & SOFTWARE SETTINGS DISPLAY

Provides information on the current 'Hardware & Software Settings'

DONE

To save any changes and selections made before closing and returning to the display of the five main navigation and Help buttons.

UNDO

To undo any changes and selections made in this particular part of CustoMax.

Usage Tips

- ù The Power Saver function will be executed after a predetermined period of time, during which the monitor has not been used.
- ù The new Navigation default at Start-up will be executed after you have restarted CustoMax.
- ù The CustoMax Window Background will be changed immediately after a Selection has been made.
- ù The Language will be changed immediately after a Selection has been made.
- ù Options relating to the type of monitor selected will be changed immediately after a Selection has been made.
- ù The displayed information cannot be manipulated in the area of display.




TABLE OF CONTENTS

GETTING STARTED		Advanced Controls / Rotary Default	12
Introduction	1	Advanced Controls / Power Saving	12
Safety	1	OSD Controls	13
Description of Controls	2-3	Video Input	13
Setting Up Guide	Foldout	AUDIO CONTROLS WINDOW	
HOW TO USE THE ON SCREEN DISPLAY		Mute	14
MAIN CONTROLS WINDOW		Bass	14
Brightness	4	Treble	14
Contrast	4	Balance	14
Degauss	5	GEOMETRY CONTROLS WINDOW	
Volume	5	Pincushion	15
SCREEN SIZE & POSITION WINDOW		Balanced Pincushion	15
Full Size	6	Trapezoid	15
Horizontal Position	6	Parallelogram	15
Horizontal Size	7	Rotation	15
Vertical Position	7	EXIT & RESET	16
Vertical Size	7	ADDITIONAL INFORMATION	
COLOR TEMPERATURE WINDOW		BNC & USB Set Ups	17
9300 K CAD/CAM	8	Audio Hook Ups & Power Saving Feature	18
6500 K DTP	8	Pin Assignment	19
5500 K Photo Retouch	8	Specifications	19
User Presets	9	Index	19
SPECIAL CONTROLS WINDOW		Glossary	19
Language	10	Troubleshooting	20
Advanced Controls / Corner Correction	10	Warranty	21
Advanced Controls / Vertical Linearity	11		
Advanced Controls / Moire	11		

OTHER LANGUAGE VERSIONS

FRENCH (FRANCAIS)	22	SPANISH (ESPAÑOL)	44
-------------------------	----	-------------------------	----

INTRODUCTION AND SAFETY



Introduction

The Philips Brilliance 109 color monitor displays sharp and brilliant images of text and graphics with a maximum resolution of 1600x1200 pixels. It is optimal for Windows, CAD / CAM / CAE, desktop publishing, spread sheets, multi-media, and any other application that demands a large screen size and high resolutions.

The monitor automatically scans horizontal frequencies from 30KHz to 95KHz, and vertical frequencies from 50Hz to 160Hz. With microprocessor-based digital-controlled circuitry and On-Screen Display (OSD) controls, the monitor can automatically adjust itself to the video card's scanning frequency and displays an image with the precise parameters you desire.

Features

- An anti-glare, anti-static, and anti-reflection high-contrast screen coating eliminates any bad effects caused by room light reflecting on and dust attracted to the screen's surface.
- With the Color Adjustment feature, you can easily choose different preset color temperatures or set your own customized color parameters.
- The Image Tilt Adjustment feature corrects a rotated image. This correction minimizes the distortions caused by elements such as the Earth's magnetic field.
- The full-size feature expands the image on the monitor to fill the screen when used in factory preset modes.

- USB Bay at back of monitor is prepared for the Universal Serial Bus hub. You can easily and flexibly connect USB-designed devices – such as a mouse or keyboard – to the monitor for true Plug-and-Play function. USB hub shipped separately.
- Green Design – including automatic power saving function (NUTEK) and low-emission compliance (TCO '95) – shows your commitment to the environment.
- DDC1/DDC2B allows communication between the monitor and the PC for optimal video configuration.
- The Power Factor Correction feature improves the power factor and results in higher power-consumption efficiency.
- Moire Cancellation eliminates diffraction, a fringe pattern in the picture.

NOTE: Your monitor operates according to the VESA DDC level 1/2B. Only computers that support the same guidelines and operate at the same or a higher level can make use of this feature. If your computer does not support the relevant guidelines, you can still use your monitor and computer. However, you may need to manually specify the appropriate resolution in the computer.

As an Energy Star Partner, Philips has determined that this product meets the Energy Star guidelines for energy efficiency.



Contact us at our web site: <http://www.monitors.be.philips.com>

Safety precautions and maintenance

- Unplug the monitor, if you are not going to use it for an extended period of time.
- Unplug the monitor, if you need to clean it with a slightly damp cloth. Wiping the screen with a dry cloth is okay when the power is off. However, never use alcohol or ammonia-based liquids.
- Consult a service technician if the monitor does not operate normally when following the instructions in this manual.
- The back cover should be removed only by qualified service personnel.
- Keep the monitor out of direct sunlight and away from stoves or any other heat source.
- The top of the monitor is not a shelf. Remove any object that could fall into the vents or prevent proper cooling of the monitor's electronics.
- Keep the monitor dry. To avoid electric shock, do not expose it to rain or excessive moisture.
- Keep the monitor away from magnetic objects, such as speakers, electric motors, transformers, etc.
- When positioning the monitor, make sure the power plug and outlet are easily accessible.




End-of-life disposal

Your new monitor contains materials that can be recycled and reused. Specialized companies can recycle your product to increase the amount of reusable materials and to minimize the amount to be disposed of.

Please find out about the local regulations on how to dispose of your old monitor.

ENERGY STAR is a U.S. registered mark.
IBM, IBM PC, and Power PC are registered trademarks of International Business Machines Corporation.
Apple, Macintosh, Quadra, Performa, and Centris are registered trademarks of Apple Computer, Inc.
PCS 90 049


DESCRIPTION OF CONTROLS



DESCRIPTION OF CONTROLS




PEDESTAL



PEDESTAL – With the built-in pedestal, you can tilt and swivel the monitor to the most comfortable viewing angle. To best use your monitor, always place it at eye level.

FRONT-PANEL MUTE BUTTON



USING THE FRONT-PANEL MUTE BUTTON
– To turn the mute ON and OFF, first press the MUTE button. Next, turn the ROTARY knob to highlight either ON or OFF. Then, press the MUTE button again. *For another way to mute the sound, see page 14.*

ON SCREEN DISPLAY – Your monitor is preset at the factory. However, you can adjust it using the On Screen Display button and the ROTARY knob described on page 2. The way to do so is through the On Screen Display (OSD). Below is a brief description of the six On Screen Display windows.

MAIN CONTROLS – The first window highlighted after the OSD has been selected. It has four features: BRIGHTNESS, CONTRAST, DEGAUSS, and VOLUME. To adjust these features, turn to pages 4 - 5.

SCREEN SIZE & POSITION – The second window highlighted after the OSD has been selected. It has five features: FULL SIZE, HORIZONTAL POSITION, HORIZONTAL SIZE, VERTICAL POSITION, and VERTICAL SIZE. To adjust these features, turn to pages 6 - 8.

COLOR TEMPERATURE – The third window highlighted after the OSD has been selected. It has four features: CAD/CAM, DTP, PHOTO RETOUCH, and USER PRESETS. To adjust these features, turn to pages 8 - 9.

SPECIAL CONTROLS – The fourth window highlighted after the OSD has been selected. It has four features: LANGUAGE, ADVANCED CONTROLS, OSD CONTROLS, and VIDEO INPUT. To adjust these features, turn to pages 10 - 13.
Note: LANGUAGE allows you to change the On Screen Display from English to French, Spanish, German, or Italian. See page 10 for details.

GEOMETRY CONTROLS – The sixth window highlighted after the OSD has been selected. It has five features: PINCUSHION, BALANCED PINCUSHION, TRAPEZOID, PARALLELOGRAM, and ROTATION. To adjust these features, turn to page 15.


AUDIO CONTROLS – The fifth window highlighted after the OSD has been selected. It has four features: MUTE, BASS, TREBLE, and BALANCE. To adjust these features, turn to page 14.

HOW TO USE THE ON SCREEN DISPLAY (OSD)

MAIN CONTROLS WINDOW

BRIGHTNESS

To adjust your screen's brightness, follow the steps below. Brightness is the overall intensity of the light coming from the screen. A 50% brightness level is recommended.




SMART HELP

After returning to MAIN CONTROLS ...
... to continue to CONTRAST, turn the ROTARY knob until CONTRAST icon is highlighted. Next, follow steps 3 - 5 under CONTRAST.
... to exit completely, press the OSD button and hold for two seconds. (See page 16 for other exit options.)

CONTRAST

To adjust your screen's contrast, follow the steps below. Contrast is the difference between the light and dark areas on the screen. A 100% contrast level is recommended.




SMART HELP

After returning to MAIN CONTROLS ...
... to continue to DEGAUSS, turn the ROTARY knob until DEGAUSS icon is highlighted. Next, follow steps 3 - 4 under DEGAUSS (on the next page).
... to exit completely, press the OSD button and hold for two seconds. (See page 16 for other exit options.)


HOW TO USE THE ON SCREEN DISPLAY (OSD)

MAIN CONTROLS WINDOW



DEGAUSS


- 1 To degauss your screen, follow the steps below. Degaussing removes electromagnetic build up that may distort the color on your screen.



- 1 Press the On Screen Display button.

- 2 Press the On Screen Display button. Next, turn the ROTARY knob until the DEGAUSS icon is highlighted.

For a moment, the screen will be distorted. Then it will return to normal. You will be back at the MAIN CONTROLS window.



- 3 Press the On Screen Display button to degauss your screen.

SMART HELP


After returning to MAIN CONTROLS ...

... to continue to VOLUME, turn the ROTARY knob until VOLUME icon is highlighted. Next, follow steps 3 - 5 under VOLUME.

... to exit completely, press the OSD button and hold for two seconds. (See page 16 for other exit options.)

VOLUME

- 1 To adjust your monitor's volume, follow the steps below. The volume control adjusts the sound from the two front-mounted speakers or the earphones jack.




- 1 Press the On Screen Display button.


- 2 Press the On Screen Display button. Next, turn the ROTARY knob until the VOLUME icon is highlighted.



- 3 Press the On Screen Display button to return to MAIN CONTROLS window.



- 4 Press the On Screen Display button to bring up VOLUME screen.




- 5 Turn the ROTARY knob (at the lower right-hand corner of the monitor) to adjust the volume.

SMART HELP

After returning to MAIN CONTROLS ...

... to continue to SCREEN SIZE & POSITION window, turn the ROTARY knob until EXIT is highlighted. Next, press the OSD button. Turn to the next page and follow steps 2 - 5 under FULL SIZE.

... to exit completely, press the OSD button and hold for two seconds. (See page 16 for other exit options.)




HOW TO USE THE ON SCREEN DISPLAY (OSD)

SCREEN SIZE & POSITION WINDOW


FULL SIZE

- 1 Full Size allows you to adjust the image on your screen to its maximum height and width. If nothing happens when you use this feature, the image is already at full size. You can use Full Size to both enable and disable this feature. *Note: Full Size only works with the monitor's factory presets.*




- 1 Press the On Screen Display button.

- 2 Turn the ROTARY knob until the SCREEN SIZE & POSITION window is highlighted. Next, press the On Screen Display button. The FULL SIZE icon is highlighted.



The image will automatically adjust to full size. You can now go on to your next adjustment.

- 3 Press the On Screen Display button.



SMART HELP


After returning to SCREEN SIZE & POSITION ...

... to continue to HORIZONTAL POSITION, turn the ROTARY knob until HORIZONTAL POSITION is highlighted. Next, follow steps 3 - 5 under HORIZONTAL POSITION.

... to exit completely, press the OSD button and hold for two seconds. (See page 16 for other exit options.)


HORIZONTAL POSITION

- 1 Horizontal Position shifts the image on your screen either to the left or right. Use this feature if your image does not appear centered.



- 1 Press the On Screen Display button.

- 2 Turn the ROTARY knob until the SCREEN SIZE & POSITION window is highlighted. Next, press the On Screen Display button. Then, turn the ROTARY knob until HORIZONTAL POSITION is highlighted.



- 3 Press the On Screen Display button to return to SCREEN SIZE & POSITION.

- 4 Press the On Screen Display button to bring up HORIZONTAL POSITION screen.



- 5 Turn the ROTARY (at the lower right-hand corner of the monitor) knob until the image is horizontally balanced.

SMART HELP


After returning to SCREEN SIZE & POSITION ...

... to continue to HORIZONTAL SIZE, turn the ROTARY knob until HORIZONTAL SIZE is highlighted. Next, follow steps 3 - 5 under HORIZONTAL SIZE (on the next page).

... to exit completely, press the OSD button and hold for two seconds. (See page 16 for other exit options.)


HOW TO USE THE ON SCREEN DISPLAY (OSD)

SCREEN SIZE & POSITION WINDOW




HORIZONTAL SIZE

Horizontal Size expands or contracts the image on your screen, pushing it out toward the left and right sides or pulling it in toward the center.



1 Press the On Screen Display button.

2 Turn the ROTARY knob until the SCREEN SIZE & POSITION window is highlighted. Next, press the On Screen Display button. Then, turn the ROTARY knob until HORIZONTAL SIZE is highlighted.



5 Press the On Screen Display button to return to SCREEN SIZE & POSITION.

6 Press the On Screen Display button to bring up HORIZONTAL SIZE screen.



7 Turn the ROTARY knob (at the lower right-hand corner of the monitor) until the image is the horizontal size you want.

SMART HELP


After returning to SCREEN SIZE & POSITION ...

... to continue to VERTICAL POSITION, turn the ROTARY knob until VERTICAL POSITION is highlighted. Next, follow steps 3 - 5 under VERTICAL POSITION.

... to exit completely, press the OSD button and hold for two seconds. (See page 16 for other exit options.)


VERTICAL POSITION VERTICAL SIZE

Vertical Position adjusts the image on your screen either up or down. Use this feature if your image does not appear centered. Vertical Size expands or contracts the image on your screen, pushing it out toward the top and bottom sides or pulling it in toward the center.




1 Press the On Screen Display button.

2 Turn the ROTARY knob until the SCREEN SIZE & POSITION window is highlighted. Next, press the On Screen Display button. Then, turn the ROTARY knob until VERTICAL POSITION or VERTICAL SIZE is highlighted.



5 Press the On Screen Display button to return to SCREEN SIZE & POSITION.

6 Press the On Screen Display button to bring up VERTICAL POSITION or VERTICAL SIZE screen.



7 Turn the ROTARY knob until the image is vertically balanced or the vertical size you want.

SMART HELP


After returning to SCREEN SIZE & POSITION ...

... to continue to GEOMETRY WINDOW, turn the ROTARY knob until EXIT is highlighted. Next, press the OSD button. Then follow steps 2a - 2c under GEOMETRY WINDOW on the next page.

... to exit completely, press the OSD button and hold for two seconds. (See page 16 for other exit options.)


HOW TO USE THE ON SCREEN DISPLAY (OSD)

COLOR TEMPERATURE WINDOW




USER PRESETS

If you need to adjust any of the three preset options (CAD/CAM, DTP, or PHOTO RETOUCH), follow the steps below to modify the colors that appear on your screen. You can make individual adjustments to each of the preset options.



1 Press the On Screen Display button.


2 Turn the ROTARY knob until the COLOR window is highlighted. Next, press the On Screen Display button. Then, turn the ROTARY knob until USER PRESETS icon is highlighted.



3 Press the On Screen Display button to bring up the User PRESETS window.



4 You will now be back at the User PRESETS window. See SMART HELP below for options.




4 If necessary, turn the ROTARY knob until 1A of the User PRESETS is highlighted. Next, press the On Screen Display button.


8 To exit User PRESET 1, press the On Screen Display button. Next, turn the ROTARY knob until the EXIT box is highlighted. Then, press the On Screen Display button.




7 When done with green, press the On Screen Display button. BLUE will be highlighted.



6 When done with red, press the On Screen Display button. GREEN will be highlighted.



5 First, press the On Screen Display button. RED will be highlighted.



To adjust the blue, press the On Screen Display button again. Then, turn the ROTARY knob to increase or decrease the blue.



To adjust the green, press the On Screen Display button again. Then, turn the ROTARY knob to increase or decrease the green.



Next, to adjust the red, press the On Screen Display button again. Then, turn the ROTARY knob to increase or decrease the red.

SMART HELP

USER PRESETS

GO BACK

1A 2A


To exit User PRESETS (step 3 above), turn the ROTARY knob until the Go Back icon is highlighted. Go BACK appears by the icon when highlighted. Next, press the On Screen Display button. You will be back at the COLOR TEMPERATURE window.

After returning to COLOR TEMPERATURE ...

... to continue to User PRESET 2 or 3, repeat steps 3 through 8, selecting either User PRESET 2 or User PRESET 3.

... to continue to SPECIAL CONTROLS window, turn the ROTARY knob until EXIT is highlighted. Next, press the On Screen Display button. Then, turn the ROTARY knob until SPECIAL CONTROLS is highlighted. Now, follow steps 2 - 5 under SPECIAL CONTROLS on the next page.

... to exit the On Screen Display completely, press the OSD button and hold for two-seconds. (See page 16 for other exit options.)




HOW TO USE THE ON SCREEN DISPLAY (OSD)

COLOR TEMPERATURE WINDOW

9300 K CAD/CAM / 6500 K DTP
5500 K PHOTO RETOUCH


1 2 3 Your monitor has three preset options you can choose from. One 1 for Computer Aided Design (CAD) work. Two 2 for Desktop Publishing (DTP). And three 3 for Photo Retouch. When you select an option, the computer automatically adjusts itself for that selection.



1 Press the On Screen Display button.




2 Turn the Rotary knob until the Color window is highlighted. Then press the On Screen Display button.



3 Turn the Rotary knob until CAD/CAM, DTP, or PHOTO RETOUCH is highlighted.

After each preset setting is saved, the on screen display automatically returns to the Color Temperature window. To save the next present setting, simply repeat the steps listed here.




4 Press the On Screen Display button to bring up and save the preset settings for 9300 K CAD/CAM, 6500 K DTP, or 5500 K PHOTO RETOUCH.

SMART HELP

After returning to COLOR TEMPERATURE ...

- ... to continue to USER PRESETS, turn the ROTARY knob until USER PRESETS is highlighted. Next, follow steps 3 - 9 under USER PRESETS on the next page.
- ... to exit completely, press the OSD button and hold for two seconds. (See page 16 for other exit options.)




HOW TO USE THE ON SCREEN DISPLAY (OSD)


SPECIAL CONTROLS WINDOW

LANGUAGE


The On Screen Display shows its settings in one of five languages. The default is English, but you can select French, Spanish, German, or Italian.



1 Press the On Screen Display button.




2 Turn the ROTARY knob until SPECIAL CONTROLS is highlighted. Then, press the On Screen Display button to highlight LANGUAGE icon.



3 Press the On Screen Display button to confirm your selection and return to SPECIAL CONTROLS.

4 Press the On Screen Display button to bring up LANGUAGE screen.



5 Turn the ROTARY knob (at the lower right-hand corner of the monitor) until desired language is selected.


SMART HELP

After returning to SPECIAL CONTROLS ...

- ... to continue to ADVANCED CONTROLS, turn the ROTARY knob until ADVANCED CONTROLS icon is highlighted. Next, follow steps 3 - 6 under ADVANCED CONTROLS.
- ... to exit completely, press the OSD button and hold for two seconds. (See page 16 for other exit options.)

ADVANCED CONTROLS CORNER CORRECTION


ADVANCED CONTROLS is a set of five adjustments. They include CORNER CORRECTION, VERTICAL LINEARITY, MOIRE, ROTARY DEFAULT, and POWER SAVING. CORNER CORRECTION "squares up" the corners of an image on the screen to adjust your CORNER CORRECTION, follow the steps below.



1 Press the On Screen Display button.



2 Turn the ROTARY knob until SPECIAL CONTROLS is highlighted. Next, press the On Screen Display button. Then, turn the ROTARY knob until the ADVANCED CONTROLS icon is highlighted.




3 Press the On Screen Display button to bring up ADVANCED CONTROLS screen.



4 Turn the ROTARY knob until desired corner correction is selected.

5 Press the On Screen Display button to bring up ADVANCED CONTROLS screen.



If necessary, turn the ROTARY knob until CORNER CORRECTION is highlighted. Then, press the On Screen Display button.


SMART HELP

After returning to ADVANCED CONTROLS ...

- ... to continue to VERTICAL LINEARITY, turn the ROTARY knob until VERTICAL LINEARITY icon is highlighted. Next, follow steps 4 - 6 under VERTICAL LINEARITY (on the next page).
- ... to exit completely, press the OSD button and hold for two seconds. (See page 16 for other exit options.)

HOW TO USE THE ON SCREEN DISPLAY (OSD)

SPECIAL CONTROLS WINDOW



ADVANCED CONTROLS VERTICAL LINEARITY

ADVANCED CONTROLS is a set of five adjustments, including VERTICAL LINEARITY. Linearity is the degree with which the actual location of a pixel on the screen corresponds with its intended location. To adjust your VERTICAL LINEARITY, follow the steps below.

- Press the On Screen Display button.
- Turn the ROTARY knob until SPECIAL CONTROLS is highlighted. Next, press the On Screen Display button. Then, turn the ROTARY knob until the ADVANCED CONTROLS icon is highlighted.
- Press the On Screen Display button to add your adjustment and to bring up ADVANCED CONTROLS screen.
- Turn the ROTARY knob to adjust the vertical linearity.
- Press the On Screen Display button to bring up ADVANCED CONTROLS screen.
- Turn the ROTARY knob until VERTICAL LINEARITY is highlighted. Then, press the On Screen Display button.

SMART HELP

After returning to ADVANCED CONTROLS ...

... to continue to MOIRE, turn the ROTARY knob until MOIRE icon is highlighted. Next, follow steps 4 - 7 under MOIRE.
... to exit completely, press the OSD button and hold for two seconds. (See page 16 for other exit options.)

ADVANCED CONTROLS MOIRE

ADVANCED CONTROLS is a set of five adjustments, including MOIRE. MOIRE is a fringe pattern arising from the interference between two superimposed line patterns. To adjust your MOIRE, follow the steps below. *Note: Use only if necessary. By activating MOIRE, sharpness can be affected.*

- Press the On Screen Display button.
- Turn the ROTARY knob until SPECIAL CONTROLS is highlighted. Next, press the On Screen Display button. Then, turn the ROTARY knob until the ADVANCED CONTROLS icon is highlighted.
- Press the On Screen Display button to add your adjustment and to bring up ADVANCED CONTROLS screen. See SMART HELP to select VERTICAL MOIRE or turn MOIRE Off.
- Turn the ROTARY knob to adjust the moire.
- Press the On Screen Display button to bring up ADVANCED CONTROLS screen.
- Turn the ROTARY knob until HORIZONTAL MOIRE is highlighted. Then, press the On Screen Display button.
- Turn the ROTARY knob until MOIRE is highlighted. Then, press the On Screen Display button.

SMART HELP


To select VERTICAL MOIRE or to turn Moire off, follow the steps above, selecting VERTICAL MOIRE or MOIRE off in step 5.

After returning to ADVANCED CONTROLS ...

... to continue to ROTARY DEFAULT, turn the ROTARY knob until ROTARY DEFAULT icon is highlighted. Next, follow steps 4 - 6 under ROTARY DEFAULT. ... to exit completely, press the OSD button and hold for two seconds. (See page 16 for other exit options.)

HOW TO USE THE ON SCREEN DISPLAY (OSD)

SPECIAL CONTROLS WINDOW



ADVANCED CONTROLS ROTARY DEFAULT

ROTARY DEFAULT allows you to pick the feature your ROTARY knob will default to when not used in adjusting your On Screen Display. The normal default is volume. To select your ROTARY DEFAULT, follow the steps below.

- Press the On Screen Display button.
- Turn the ROTARY knob until SPECIAL CONTROLS is highlighted. Next, press the On Screen Display button. Then, turn the ROTARY knob until the ADVANCED CONTROLS icon is highlighted.
- Press the On Screen Display button to add your adjustment and return to ADVANCED CONTROLS.
- Turn the ROTARY knob to select BRIGHTNESS, CONTRAST, or VOLUME.
- Press the On Screen Display button to bring up ADVANCED CONTROLS screen.
- Turn the ROTARY knob until ROTARY DEFAULT is highlighted. Then, press the On Screen Display button.

SMART HELP

After returning to ADVANCED CONTROLS ...

... to continue to POWER SAVING, turn the ROTARY knob until POWER SAVING is highlighted. Next, follow steps 3 - 6 under POWER SAVING.
... to exit completely, press the OSD button and hold for two seconds. (See page 16 for other exit options.)

ADVANCED CONTROLS POWER SAVING

POWER SAVING helps save energy when the monitor is on but not being used. After a preset time, the monitor will go blank if not being used. To select POWER SAVING, follow the steps below.

- Press the On Screen Display button.
- Turn the ROTARY knob until SPECIAL CONTROLS is highlighted. Next, press the On Screen Display button. Then, turn the ROTARY knob until the ADVANCED CONTROLS icon is highlighted.
- Press the On Screen Display button to add your adjustment and return to ADVANCED CONTROLS.
- Turn the ROTARY knob to select POWER SAVING On or Off.
- Press the On Screen Display button to bring up ADVANCED CONTROLS screen.
- Turn the ROTARY knob until POWER SAVING is highlighted. Then, press the On Screen Display button.


SMART HELP

After returning to ADVANCED CONTROLS ...

... to continue to OSD CONTROLS, turn the ROTARY knob until GO BACK is highlighted. Next, press the On Screen Display button. Then, turn the ROTARY knob to OSD CONTROLS and go to the next page.
... to exit completely, press the OSD button and hold for two seconds. (See page 16 for other exit options.)

HOW TO USE THE ON SCREEN DISPLAY (OSD)




SPECIAL CONTROLS WINDOW



OSD CONTROLS

With OSD CONTROLS, you can set the time for the On Screen Display to time out, and change the vertical and horizontal position of the OSD on the monitor screen.

- 1 Press the On Screen Display button.
- 2 Turn the ROTARY knob until SPECIAL CONTROLS is highlighted. Next, press the On Screen Display button. Then, turn the ROTARY knob until the OSD CONTROLS icon is highlighted.
- 3 Turn the ROTARY knob to select either VERTICAL or HORIZONTAL Position and repeat steps 3 - 6.
- 4 Press the On Screen Display button to add your change and return to OSD CONTROLS.
- 5 Press the On Screen Display button to bring up OSD CONTROLS screen.
- 6 Turn the ROTARY knob to select 05, 10, 25 seconds, or OFF.
- 7 Press the On Screen Display button to bring up TIMER screen.
- 8 Turn the ROTARY knob to select either 0.7V or 1.0V.



VIDEO INPUT

VIDEO INPUT helps determine what you see on the screen. It is set at 0.7V (olts), but if the video input signal is different than the output signal, you may want to change it to 1.0V.

- 1 Press the On Screen Display button.
- 2 Turn the ROTARY knob until SPECIAL CONTROLS is highlighted. Next, press the On Screen Display button. Then, turn the ROTARY knob until the VIDEO INPUT icon is highlighted.
- 3 Press the On Screen Display button to save your selection and return to SPECIAL CONTROLS.
- 4 Press the On Screen Display button. The VIDEO INPUT screen appears.
- 5 Turn the ROTARY knob to select either 0.7V or 1.0V.



SMART HELP

After returning to SPECIAL CONTROLS ...

... to continue to OSD CONTROLS, turn the ROTARY knob until OSD CONTROLS icon is highlighted. The follow steps 3 - 6 under OSD CONTROLS.



... to exit completely, press the OSD button and hold for two seconds. (See page 16 for other exit options.)

SMART HELP

After returning to OSD CONTROLS ...

... to continue to AUDIO CONTROLS, turn the ROTARY knob until GO BACK is highlighted. Next, press the On Screen Display button. Then, turn the ROTARY knob to AUDIO CONTROLS window and go to the next page.

... to exit completely, press the OSD button and hold for two seconds. (See page 16 for other exit options.)





HOW TO USE THE ON SCREEN DISPLAY (OSD)

AUDIO CONTROLS WINDOW


MUTE, BASS, TREBLE, BALANCE

Follow the steps below to modify the sound that comes from your speakers. You can make individual adjustments to each of the preset options (MUTE, BASS, TREBLE, or BALANCE).

- 1 Press the On Screen Display button.
- 2a Press the On Screen Display button to mute the sound from your speakers and to return to AUDIO CONTROLS window. MUTE ON appears at the top of the on screen display.
- 2b Press the On Screen Display button to unmute the sound from your speakers and to return to AUDIO CONTROLS window. MUTE OFF appears at the top of the on screen display.
- 3a To select BASS, turn the ROTARY knob until BASS icon is highlighted. Next, press the On Screen Display button.
- 3b Turn the ROTARY knob to adjust the bass.
- 3c To select TREBLE, turn the ROTARY knob until TREBLE icon is highlighted. Next, press the On Screen Display button.
- 3d Turn the ROTARY knob to adjust the treble.
- 3e To select BALANCE, turn the ROTARY knob until BALANCE icon is highlighted. Then, press the On Screen Display button.
- 3f Turn the ROTARY knob to adjust the balance.
- 4a When done, press the On Screen Display button to save the change and return the screen to AUDIO CONTROLS.
- 4b When done, press the On Screen Display button to save the change and return the screen to AUDIO CONTROLS.




When done, press the On Screen Display button to save the change and return the screen to AUDIO CONTROLS.




Turn the ROTARY knob to adjust the balance.




To select BALANCE, turn the ROTARY knob until BALANCE icon is highlighted. Then, press the On Screen Display button.




Turn the ROTARY knob to adjust the balance.



When done, press the On Screen Display button to save the change and return the screen to AUDIO CONTROLS.



Turn the ROTARY knob to adjust the treble.



When done, press the On Screen Display button to save the change and return the screen to AUDIO CONTROLS.

SMART HELP

To exit AUDIO CONTROLS ...

... but continue on to GEOMETRY CONTROLS, turn the ROTARY knob until EXIT is highlighted. Next, press the On Screen Display button. Then go to step 2a on page 15.


... completely, press the On Screen Display button and hold for two seconds. The On Screen Display will disappear. All changes will be saved.

To cancel Mute, repeat step 2b, or press the MUTE button on the front of the monitor.

To make changes to one item, follow the steps for that item. Then follow the instructions To exit AUDIO CONTROLS ...


HOW TO USE THE ON SCREEN DISPLAY (OSD)

GEOMETRY CONTROLS WINDOW




PINCUSHION, BALANCED PINCUSHION, TRAPEZOID, PARALLELOGRAM, ROTATION

Follow the steps below to adjust any of the five preset options (PINCUSHION, BALANCED PINCUSHION, TRAPEZOID, PARALLELOGRAM, or ROTATION). You can make individual adjustments to each of the preset options. *Note: use these features only when the picture is not square.*



1 Press the On Screen Display button.

2a Turn the ROTARY knob until the GEOMETRY CONTROLS window is highlighted. Next, press the On Screen Display button. Then, if necessary, turn the ROTARY knob until PINCUSHION icon is highlighted.



2b Press the On Screen Display button. Then, turn the ROTARY knob to adjust the pincushion.



2c When done, press the On Screen Display button to save the change and return to GEOMETRY CONTROLS window.



3a To select BALANCED PINCUSHION, turn the ROTARY knob until BALANCED PINCUSHION is highlighted. Next, press the On Screen Display button.



3b Turn the ROTARY knob (on the lower right-hand corner of the monitor) to adjust the balanced pincushion.



3c When done, press the On Screen Display button. This will save the change and return the screen to GEOMETRY CONTROLS.



4a To select TRAPEZOID, turn the ROTARY knob until TRAPEZOID icon is highlighted. Next, press the On Screen Display button.



4b Turn the ROTARY knob to adjust the trapezoid.



SMART HELP


To exit GEOMETRY CONTROLS ...

... but continue to another window, turn the ROTARY knob until EXIT is highlighted. Next, press the On Screen Display button. Then, turn the ROTARY knob until that window is highlighted. Now, press the On Screen Display button and follow the instructions for that window.

... completely, press the On Screen Display button and hold for two seconds. The On Screen Display will disappear. All changes will be saved.

To make changes to one item, follow the steps for that item. Then, follow "To exit GEOMETRY CONTROLS ..."

To return to factory presets, see "To Reset an Individual Window" on page 16.




HOW TO USE THE ON SCREEN DISPLAY (OSD)

EXIT AND RESET


EXIT & RESET FROM A WINDOW

Choosing EXIT allows you to go to another window. Choosing RESET returns all the settings in that window to factory presets.


TO EXIT AN INDIVIDUAL WINDOW



1 Make sure you are in a window. For example, MAIN CONTROLS. An icon will be highlighted. For example, BRIGHTNESS.




2 Turn the ROTARY knob until EXIT is highlighted. Next, press the On Screen Display button.




3 An entire window is now highlighted. Turn the ROTARY knob to another window and begin adjustments, or turn the knob until EXIT is highlighted as shown in EXIT FROM OSD (at right).


TO RESET AN INDIVIDUAL WINDOW



1 Make sure you are in a window. For example, MAIN CONTROLS. An icon will be highlighted. For example, BRIGHTNESS.



2 Turn the ROTARY knob until RESET is highlighted. Next, press the On Screen Display button.




3 The first icon in the reset window is now highlighted. Turn the ROTARY knob to select another icon and begin adjustments, or turn the knob until EXIT is highlighted as shown above.


EXIT & RESET FROM THE ON SCREEN DISPLAY

Exiting from the On Screen Display removes the On Screen Display from the monitor screen. Resetting from the On Screen Display returns everything in all the windows to factory presets.


TO EXIT AN ENTIRE ON SCREEN DISPLAY




1 Make sure you have exited from all icons in a window. (See To Exit from an individual window.) For example, MAIN CONTROLS will be highlighted.




2 Turn the ROTARY knob until EXIT is highlighted. Next, press the On Screen Display button. The On Screen Display will disappear.




RESET ENTIRE ON SCREEN DISPLAY




1 Make sure you have exited from all icons in a window. (See To Exit from an individual window.) For example, MAIN CONTROLS will be highlighted.



2 Turn the ROTARY knob until RESET is highlighted. Next, press the On Screen Display button.



3 Turn the ROTARY knob to select No or Yes. Then press the On Screen Display button.




4 If No is selected, the On Screen Display appears and MAIN CONTROLS is highlighted.

If Yes is selected, the Exit OSD screen appears.

ADDITIONAL HOOK UP OPTIONS

BNC AND USB SET UPS



BNC CONNECTIONS

BNC is another way to connect the monitor to the computer. This connection requires an optional BNC cable. It can be connected to either a Macintosh- or IBM-compatible computer. For those who work with graphics or designs, this option may be better.

Note: Be sure to flip the D-Sub/BNC switch to BNC when using this connection.


For an IBM-compatible computer:

1. Turn off the computer.
2. Connect the (optional) BNC monitor cable and set D-Sub/BNC switch to BNC.
3. Connect the power cable.
4. Turn on the monitor. Then turn on the computer.
5. If you have Windows '95, follow the "If you have Windows '95" steps on the Setting Up foldout sheet.

For a Macintosh-type computer:

1. Connect the Mac adapter to one end of the monitor cable.
2. Turn off the computer.
3. Connect the (optional) BNC monitor cable and set D-Sub/BNC switch to BNC.
4. Connect the power cable.
5. Turn on the monitor. Then turn on the computer.

D-Sub/BNC Switch



Refer to the "Setting Up your Philips monitor" foldout for a more detailed guide to setting up your monitor.


USB CONNECTIONS

USB (Universal Serial Bus) is an innovation in connecting your IBM-compatible computer to your monitor. By using the USB, you will be able to connect your keyboard, mouse, printer, and other peripherals to your monitor instead of having to connect them to your computer. This will give you greater flexibility in setting up your system. Plus, you will have true plug-and-play capability. While the software is still being developed, Philips has included the hardware so you will be ready to take advantage of this next generation in computer development.

For an IBM-compatible Computer:

1. Turn off the computer.
2. Connect the (optional) USB Hub and cable to the computer and to the monitor. (Computer must have USB port.)
3. Connect the power cable.
4. Turn on the monitor. Then turn on the computer.
5. With the installation of the correct software, you will be able to connect specially-made peripherals to the monitor.


Note: USB Hub and cables sold separately. USB Bay exists in back of monitor.



Refer to the "Setting Up your Philips monitor" foldout for a more detailed guide to setting up your monitor.

ADDITIONAL INFORMATION

AUDIO HOOK UPS AND POWER SAVING FEATURE




MICROPHONE AND EARPHONES JACKS

In addition to built-in speakers and microphone, you can connect this monitor to optional earphones and a microphone. The jacks are on the right side of the monitor.

To use the microphone with your computer or an amplifier, make the connections shown below.

Note: When the earphones are plugged in, there will be no sound from the built-in speakers.




MICROPHONE AND AUDIO-IN JACKS

A microphone jack is on the back of the monitor. Use it and the supplied cable to connect your monitor to your computer or an amplifier (if either has the right type of jack).

On the back of this monitor there is also one set of left and right audio-in jacks. Use them and the supplied cable to connect your monitor to your computer or an amplifier (if either has the right type of jacks).

See page 2 for more detailed illustrations of the jacks' locations.



Refer to the owner's manuals included with your earphones and microphone for a detailed guide to setting up these items.

AUTOMATIC POWER SAVINGS & PRESET RESOLUTION MODES

If you have VESA's DPMS compliance display card or software installed in your PC, the monitor can automatically reduce its power consumption when not in use. If input from a keyboard, mouse, or other device is detected, the monitor automatically "wakes up." The table at left shows the power consumption and signalling of this automatic power-saving feature. To turn this feature on and off, see page 12. The table at right shows the 12 factory preset resolution modes. The maximum number of modes is 16. This leaves room for additions.

Power Management Definition						
VESA's mode	Video	H-sync	V-sync	Power used	Power saving(%)	LED color
ON	Active	Yes	Yes	<130W	0%	Green
Stand-by	Blanked	No	Yes	<15W	87.5%	Yellow
Suspend	Blanked	Yes	No	<15W	87.5%	Yellow
OFF	Blanked	No	No	<5W	95.8%	Amber

This monitor is Energy Star compliant and power management compatible.



AS AN ENERGY STAR PARTNER, PHILIPS HAS DETERMINED THAT THIS PRODUCT MEETS THE ENERGY STAR GUIDELINES FOR ENERGY EFFICIENCY.

The proper operation of the function requires a computer with VESA DPMS power management capabilities. When used with a computer equipped with VESA DPMS, the monitor is Energy Star compliant.

Factory Preset Resolution Modes				
MODE	RESOLUTION	H. FREQ. (KHz)	V. FREQ. (Hz)	STANDARD
1	640 x 400	31.5	70	VGA
2	640 x 480	31.5	60	VGA
3	640 x 480	37.5	75	VESA/75
4	800 x 600	46.9	75	VESA/75
5	800 x 600	53.7	85	VESA/85
6	1024 x 768	60	75	VESA/75
7	1024 x 768	68.6	85	VESA/85
8	1152 x 870	69.0	75	MAC
9	1152 x 900	71.8	76	SUN SPARC
10	1280 x 1024	80.0	75	VESA/75
11	1280 x 1024	91.0	85	VESA/85
12	1600 x 1200	93.8	75	VESA/75

ADDITIONAL INFORMATION


COMING TO TERMS WITH THIS BOOK



PIN ASSIGNMENT

The 15-pin D-sub connector (male) of the signal cable:

Pin No.	Assignment
1	Red video input
2	Green video input
3	Blue video input
4	Identical output - connected to pin 10
5	Self test
6	Red video ground
7	Green video ground
8	Blue video ground
9	No pin
10	Logic ground
11	Identical output - connected to pin 10
12	Serial data line (SDA)
13	H. Sync / H+V
14	V. Sync (VCLK for DDC)
15	Data clock line (SCL)



INDEX

Audio Controls	3, 14	On Screen Display	2
Automatic Power Saving	18	OSD button	2
Balance	14	OSD Controls	13
Balanced Pincushion	15	Parallelogram	15
Bass	14	Pedestal	2
BNC jacks	2	Photo Retouch	8, 9
BNC set up	17	Pin Assignment	19
Brightness	4	Pincushion	15
Built-in microphone	2	Power button	Set Up Guide, 2
Cable Cover	2	Power plug	Set Up Guide, 2
CAD/CAM	8, 9	Power Saving	12
Color Temperature	3, 8-9	Reset	16
Contrast	4	Resolution Modes	18
Corner Correction	10	Right & Left Audio in jacks	2
Degauss	5	Rotary Default	12
Description of controls	2, 3	Rotary knob	2
D-Sub/BNC switch	2, 17	Rotation	15
DTP	8, 9	Safety precautions	1
Earphones jack	2, 17	Screen Size & Position	3, 6-8
End-of-life disposal	1	Speakers	2
Exit	16	Special Controls	3, 10-13
Features	1	Specifications	19
Full Size	6	Trapezoid	15
Geometry Controls	3, 15	Treble	14
Glossary	19	Troubleshooting	20
Hook Ups	Set Up Guide, 17		
Horizontal Position	6	USB hub	2, 17
Horizontal Size	7	USB set up	17
Language	10	User Presets	9
Main Controls	3, 4-5	Vertical Linearity	11
Maintenance	1	Vertical Position	7
Microphone jacks	2, 17	Vertical Size	7
Moire	11	Video Input	13
Monitor cable plug	2	Volume	5
Mute	14	Warranty	21
Mute button	2, 3		

SPECIFICATIONS

GENERAL

CRT

Screen size	:19" (43.2 cm) flat & square
Viewable Image Size (VIS)	:17.9"
Focusing method	:Dynamic focus
Dot pitch	:0.22 mm (horizontal)
Phosphor	:P22 or equivalent, medium short persistence

Screen treatment	:Arasec
------------------	---------

Display area

Factory preset	:340 mm (H) x 255 mm (V)
Maximum usable	:364 mm (H) x 272.5 mm (V)

Scanning frequency

Horizontal (line)	:30-95kHz (AutoScan)
Vertical (frame)	:50-160 Hz (AutoScan)

Input power

	:100-240 VAC, 50-60 Hz
--	------------------------

Power consumption

	:120 Watt normal, 130 Watt max.
--	---------------------------------

Thermal dissipation

	:341.3 BTU normal, 409.5 BTU maximum
--	--------------------------------------

Input signal

Video	:0.7 or 1.0 Vpp, 75 Ohm impedance
-------	-----------------------------------

Sync

	:Separate sync. TTL level
--	---------------------------

Pedestal

Tilt	:5° forward, 11° backward
------	---------------------------

Swivel

	:90° left, 90° right
--	----------------------

Physical

Unit dimension (WxHxD)	:485 x 490 x 515 mm
------------------------	---------------------

	:19.1" x 19.3" x 20.3"
--	------------------------

Net weight

	:24.5 kg (53.9 lbs.)
--	----------------------

Operating conditions

Temperature	:0° C - 40° C
-------------	---------------

Humidity	:10% - 90%
----------	------------

Storage conditions

Temperature	: -40° C - 60° C
-------------	------------------

Humidity	:5% - 95%
----------	-----------

GLOSSARY

Here are a few definitions that may help you.

Degauss	The process by which metal parts of the monitor are demagnetized in order to reduce screen distortion and color impurity.
D-Sub/BNC	Two ways of connecting your monitor to your computer. Your monitor comes with a D-Sub cable. For work with a heavy emphasis on graphics, a BNC cable is recommended.
Geometry	A set of controls that allows you to adjust the alignment of the picture on the monitor screen. The goal is to "square up" the picture. This is done by adjusting such items as balanced pincushion, parallelogram, rotation, and trapezoid.
Moire	A fringe pattern caused by the interference between two superimposed line patterns.
USB	Universal Serial Bus. A way to connect your computer, monitor, and peripherals for true Plug-and-Play functions.

ADDITIONAL INFORMATION

WHAT TO DO IF SOMETHING ISN'T WORKING

TROUBLESHOOTING

Having trouble? Something not working? Before calling for help, try these suggestions.

HAVING THIS PROBLEM?

No Picture
(Power LED not lit)

No Picture
(Power LED is Amber or Yellow in color)

No Picture
(Power LED is Green in color)

Screen says

NO SYNC INPUT

when you turn on the monitor.

No Color

Color appears blotchy

Missing one or more colors

Dim Picture

Picture is too large or too small

Edges of the picture are not square

Picture has a double image

Picture is not sharp

No Audio

Unstable Picture

Windows '95 cannot find your video card

CHECK THESE ITEMS

Make sure the Power cable is plugged in the wall and back of the monitor.
Power button on top of the monitor should be in the ON position.
Disconnect the monitor from the power outlet for about one minute.

Make sure the computer is turned on.
Make sure the D-Sub/BNC switch on the rear of the monitor is in the correct position. See pages 2 and 17.
Make sure the monitor cable is properly connected to your computer.
Check to see if the monitor cable has bent pins.
The Energy Saving Feature may be activated. See pages 12 and 18 for more detail.

Make the Brightness and Contrast controls are set correctly. See page 4 for details.
Make sure the D-Sub/BNC switch on the rear of the monitor is in the correct position. See pages 2 and 17.
Make sure the monitor cable is properly connected to your computer.
Check to see if the monitor cable has bent pins.
Make sure the computer Power button is on.

Make sure the D-Sub/BNC switch on the rear of the monitor is in the correct position. See pages 2 and 17.
Make sure the monitor cable is properly connected to your computer. See Setting Up foldout.
Check to see if the monitor cable has bent pins.
Make sure the computer is turned on.

If you are using a non-VESA-DDC standard video card, consult your local Philips dealer or service organization to obtain an adapter.

The picture may need degaussing. See page 5 for details.
Remove any nearby magnetic objects.
Face the monitor East for best picture quality.

Check user settings of Color Temperature. See pages 8 and 9 for details.
Make sure the monitor cable is properly connected to your computer.
Check to see if the monitor cable has bent pins.

Adjust the Brightness and Contrast controls. See page 4 for details.
Check the Video Input selection and switch from 0.7 volts to 1.0 volts or 1.0 volts to 0.7 volts. See page 13.
Check your video card and the manual instructions for it. It may be a non-VESA-DDC Standard card.

Adjust the Horizontal and/or Vertical Size. See pages 7 and 8 for details.

The geometry controls require adjusting. See page 15 for details.

Eliminate the use of a video extension cable and/or video switch box.
Face the monitor East for best picture quality.

Check to make sure Moire is switched off. See page 11.

Make sure mute is not activated. See pages 2 and 14 for details.
Rotary Default may be set to Brightness or Contrast. See page 12 for details.
Make sure the Right & Left Audio in cable is securely plugged into the monitor and the audio source.
See pages 2 and 18 for details.

Increase your refresh rate. Consult your computer manual for details.

Select "Super VGA" under STANDARD DISPLAY TYPES, or contact your video card manufacturer for the right drivers.